

地上・BS・110度CSデジタルフルハイビジョン液晶テレビ

J40SK01 取扱説明書

この度はMAXZEN製品をお買い上げいただき、誠にありがとうございます。
本製品を安心してお使いいただくために、必ずこの取扱説明書をよくお読みください。
この取扱説明書は、大切に保管していただき、不明点がある場合にご活用ください。

HDMI 端子 3系統



ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

目次

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定





その他

はじめに	
付属品を確認する	3
安全上のご注意	4
必ずお読みください	8
テレビを見る準備	
各部の名称(本体)	10
本体前面	10
本体背面	10
本体左側面端子部	11
各部の名称(リモコン)	12
スタンドの取り付け	14
リモコンの準備と使い方	15
アンテナを接続する	16
UHFアンテナ線のつなぎかた	16
BS・110度CSデジタル用アンテナ線のつなぎかた	17
B-CASカードを入れる/電源を入れる	18
チャンネル設定をする	19
はじめての設定	19
郵便番号の設定	20
録画機の準備をする	21
USBハードディスクを接続する	21
新しいUSBハードディスクを登録する	21
USBハードディスクの設定をする	22
地デジ難視対策衛星放送を受信する場合	23
基本の操作	
テレビを見る	24
番組表を見る(デジタル放送のみ)	25
デジタル放送の便利な機能を使う	26
字幕を表示する	26
文字スローを表示する	26
降雨対応放送に切り替える	26
チャンネル情報を見る/音声を切り換える	27
データ放送を見る	28
ラジオ、独立データ放送を楽しむ	28
連動データ放送を楽しむ	28
画面サイズを変える	29
録画・予約をする	30
録画機能について	30
音声を切り替える	30
その他の録画機能について	31
見ている番組を録画する	32
番組表から録画予約する	32
音声を切り替える	32
連続ドラマなどを繰り返し録画予約する	32
録画する日時を指定して録画予約する	33
録画を中止する	33
予約の確認・取消しをする	33
録画動作について	34
録画予約した番組が編成変更した場合の動作について	34
録画した番組を再生する	35
録画番組を再生する	35
録画した番組を保護する	36
録画した番組を削除する	36

外部機器との接続	
再生機器を接続する	37
HDMI端子を使う場合	37
映像端子を使う場合	38
オーディオ機器を接続する	38
パソコンを接続する	39
HDMI連動設定	40
外部入力設定	41
外部入力スキップ設定	41
HDMI1音声入力設定	41
RGBレンジ設定	42
LAN端子の接続・設定	43
アンテナの方向調整と設定	45
地上デジタルアンテナレベル	45
BS・110度CSアンテナレベル	45
BS・110度CSアンテナ電源供給	46
接続した機器の映像を見る(入力切換)	47
調整と設定	
メニュー画面の操作方法	48
画面サイズを調整する	49
映像設定メニュー	50
映像メニュー	50
映像調整	50
映像調整・詳細調整	51
音声設定メニュー	52
便利な機能を使う	53
映像を一時静止させる	53
字幕を見る	53
設定メニュー	54
おしらせ	54
機能設定	55
CEC設定	56
初期設定	56
字幕を見る	53
タイマー機能メニュー	59
オンタイマーを使う	59
オフタイマーを使う	60
その他	
地域別チャンネル表	61
故障かな?と思ったら	63
まず確認してください	63
こんな場合は故障ではありません	63
全般	63
映像	64
音声	65
デジタル放送	65
録画	66
エラーメッセージ一覧	67
デジタル放送	67
録画	68
壁掛けでご使用になるとき	69
主な仕様	70
テレビ	70
リモコン	71
外付けHDD対応機器一覧	71
保証とアフターサービス	72

付属品を確認する

ご購入のパッケージ内には、以下のものが含まれています。
付属品も含め、すべて揃っているかご確認ください。

<p>テレビ本体 ×1</p> 	<p>リモコン ×1</p> 
<p>取扱説明書 ×1</p> 	<p>保証書 ×1</p> 
<p>ミニB-CASカード ×1</p> 	<p>B-CASカード紛失防止カバー ×1</p>  <p>固定ネジ ×1</p>
<p>スタンドベース ×2</p>  <p>スタンドベース固定ネジ ×4</p>	<p>単4形乾電池 (R03) ×2</p> 

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

安全上のご注意

本製品の性能を十分に発揮させ、安全にご利用いただくためにも、「安全上のご注意」をお読みになってから、取扱説明書をよくお読みになり、正しくお使いください。

注意表示の説明

製品を正しく安全にお使いいただき、お客さまや他の人々への危害や財産への損害を防止するため、重要な内容を記載しています。次の内容(表示・図記号)をよく理解してから本文をお読みになり、記載事項をお守りください。



警告

この表示を無視して、誤った取り扱いをすると、人が死亡または重傷を負う可能性があります。



注意

この表示を無視して、誤った取り扱いをすると、人が障害を負ったり物的損害を発生する可能性があります。



禁止

○記号は行為の禁止を示します。



プラグを抜く

●記号は行為の強制を示します。(この例は「電源プラグを抜く」)



指示

強制的記号です。必ず実行していただきたいことを示します。

警告

異常や故障のとき



プラグを抜く



異音や異臭がしたら

製品が正常に機能しないとき、異常音や煙、異臭などが発生した場合は、すぐに電源プラグを抜き、テクニカルセンターにご連絡ください。



プラグを抜く



内部に水や異物が混入

製品を、雨のあたる場所や水気のある場所に置かないようにしてください。内部に水や異物が入ったら、すぐに電源プラグを抜き、テクニカルセンターにご連絡ください。



禁止



電源コードを大切に

破損した電源コードは、絶対に使わないでください。また、電源コードの上や周囲にはものを置かないでください。電源コードが破損しやすくなります。



分解禁止



改造しない、 カバーを開けない

感電を避けるため、ご自身で修理しないでください。液晶テレビのケースを開ける、または取り外すと高電圧やその他の危険要因と大変危険です。


安全上のご注意(つづき)

警告

設置するとき



プラグを抜く



電圧の確認

この製品に使う電源仕様はAC100Vです。AC100V以外を使用すると、火災・感電の原因となります。また電源プラグはコンセントの根元まで確実に差し込みください。



指示



屋外や浴室に置かない

雨のあたる屋外や水気の多い台所や浴室に置かないようにしてください。



上載せ禁止



上にものを置かない

金属類や花瓶、コップなどをテレビの上に置かないでください。

使用するとき・お手入れについて



禁止



雷が鳴りだしたら、テレビ・電源コード・アンテナ線に触れない

感電の原因となりますので、触らないようにしてください。



異物挿入禁止



異物を入れない

感電や火災を避けるため、液晶テレビのケースのいかなる開口部・孔・透き間から金属類や紙などの燃えやすいものを挿入しないでください。



禁止



電源コードを引っ張らない

電源コンセントから、電源コードを抜くときは、コードではなく、プラグ部分を持って、まっすぐに引き抜いてください。



プラグを抜く



清掃は電源プラグを抜いてから

清掃をするときは、電源プラグをコンセントから抜いてから行なってください。

安全上のご注意(つづき)


⚠️ 注意

設置するとき



温度の高い場所に置かない

直射日光のあたる場所やストーブのそばなど、温度の高い場所に置かないでください。変形や破損により感電の原因となることがあります。



設置の際は壁から離す

本棚などの通気の悪い場所に設置する場合は、本体と周囲との間にスペースを空けてください。



通風孔を塞がない

本体にある開口部は換気用です。過熱防止のため通風孔を塞がないでください。テールクロス・カーテンなどを掛けたり、じゅうたんや布団の上に置かないでください。



お子様にご注意

小さなお子様の手が届かない場所でお使いください。倒れたりしてけがの原因となることがあります。

使用するとき・お手入れについて



日本国内専用

本製品は、日本国内の一般家庭用として設計製造されています。国外で使用された場合や一般家庭用以外の用途で使用された場合は、サポート保証の対象外となります。



やさしく扱って…

液晶テレビの画面をたいたたり、衝撃を加えたりしないでください。もしも、ガラスが割れて内部の液晶(液体)が目に入ったり、皮膚についたときは、きれいな水でよく洗い流し、直ちに医師に相談してください。



長時間使用しないときは、電源プラグを抜く

長期の旅行、外出のときは電源プラグをコンセントから抜いてください。



清掃はやさしく

清掃時は、本体と付属品が破損していないかチェックします。画面またはキャビネットに直接スプレーをかけたたり、液体をこぼしたりしないでください。水または非アンモニア系、非アルコール系のガラスクリーナーを使用して、湿った柔らかいきれいな布でやさしく拭いてください。


安全上のご注意(つづき)

⚠️ 注意

使用するとき・お手入れについて(つづき)



指示



リモコンの乾電池について

- 指定以外の乾電池(マンガン電池など)は使用しない
- 極性表示とを間違えて挿入しない
- 充電・加熱・分解・ショートしたり、火の中に入れてたりしない
- 表示されている「使用推奨期限」の過ぎた乾電池や、使い切った乾電池はリモコンに入れておかない
- 種類の違う乾電池、新しい乾電池と使用した乾電池を混ぜて使用しない

上記を守らないと、液もれ・破裂などによって、やけど・けがの原因となることがあります。もれた液が目や口に入ったり、皮膚に付いたりしたときは、きれいな水でよく洗い流し、直ちに医師に相談してください。衣服に付いたときは、すぐきれいな水で洗い流してください。器具に付いたときは、液に直接触れないでふき取ってください。

使用上のお願いとご注意

取り扱いについて

- ご使用中に製品本体で熱くなる部分がありますので、ご注意ください。
- 液晶テレビではテレビゲームをお楽しみいただけますが、光線銃などを使って画面を標的にしたゲームでは、原理上使用できません。
- 外部入力映像や音声には若干の遅れが生じます。
- テレビ放送、外部入力のソースによっては、映像や音声に若干の遅れが生じる場合があります。映像、音声でリズムを取るテレビゲームやカラオケ機器によっては、違和感がありますが、故障ではありません。

液晶パネルについて

- 液晶パネルは、構造上、表示画面に黒い点(点灯しない点)、または輝点(光点)が見えることがあります。これは故障ではありませんので、あらかじめご了承ください。
- 液晶パネルは、長時間映し出しておくと、残像が出たり、液晶パネルの寿命を短縮させる場合があります。画面を見ないときは、節電機能をご利用ください。

廃棄、または譲渡するとき

- 家電リサイクル法では、お客さまがご使用済みの液晶テレビを2009年4月1日以降に廃棄される場合は、収集運搬料金、再商品化等料金(リサイクル料金)をお支払いいただき、対象品を販売店や市町村に適正に引き渡すことが求められています。
- B-CAS(ビーキャス)カードの登録廃止、登録名義変更などについては、(株)ビーエスコンディショナルアクセスシステムズにお問い合わせください。(カードが貼ってある説明書の表と裏をよくお読みください。)
- 梱包箱(外箱と梱包材)を廃棄しないでください。修理などで本製品を輸送する必要があるときに、ご利用いただくためです。また、長期間ご使用にならないときにも、梱包箱に入れて保管してください。

免責事項について

- 地震・雷などの自然災害、火災、第三者による行為、その他の事故、お客さまの故意または過失、誤用、その他異常な条件下での使用によって生じた損害に関して、当社は一切の責任を負いません。
- 本製品の故障、当社指定外の第三者による修理、その他の理由により生じた損害、および、逸失利益などに関しまして、当社は一切の責任を負いません。
- 取扱説明書の記載内容を守らないことによって生じた損害に関して、当社は一切の責任を負いません。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

必ずお読みください

地上デジタル放送を受信するには

地上デジタル(テレビジョン)放送とは?

地上波のUHF帯を使用した地上デジタル放送のことです。取扱説明書では、「地上デジタル放送」と記載しています。

<p>受信地点が、すでに放送地域になっていること 地上デジタル放送の受信エリアの目安については、下記までお問い合わせください。 総務省地上デジタルテレビジョン受信相談センター 0570-07-0101 03-4334-1111 受付:9:00~21:00(平日)9:00~18:00(土、日、祝祭日) http://www.dpa.or.jp/ (2013年1月現在)</p>	<p>UHFアンテナが必要です UHFアンテナには全帯域型と帯域専用型があります。地上デジタル放送を受信するには全帯域型または地上デジタル放送対応型のUHFアンテナをご使用ください。</p>
<p>UHFアンテナが、地上デジタル放送の送信塔の方向に向いていること 現在お住まいの地域で、地上デジタル放送の送信塔が地上アナログ放送と同じ方向の場合は、そのままの向きで地上デジタル放送を受信できます。地上デジタル放送の送信塔が違う方向の場合は、UHFアンテナの向きを地上デジタル放送の送信塔に変更してください。</p>	<p>地上デジタル入力信号に、必要な強度があること 地上デジタル放送は、現在のアナログ放送との混信を避けるために、当初は非常に小さな出力で放送されます。そのため受信エリアが限定されます。また、受信エリア内であっても、地形やビル陰などによって電波がさえぎられる場合や電波の伝搬状況などにより、視聴できない場合があります。</p>

お知らせ ケーブルテレビまたは共聴・集合住宅施設で地上デジタル放送を受信する場合は、ケーブル事業者または共聴施設管理者にお問い合わせください。

留意点

- 付属のB-CAS(ビーカス)カードは、デジタル放送を視聴していただくために、お客さまへ貸与された大切なカードです。破損や紛失などの場合は、直ちに(株)ビーエス・コンディショナルアクセスシステムズへご連絡ください。お客さまの責任で破損、故障、紛失などが発生した場合は、再発行費用が請求されます。
- お買い上げ後、より快適な環境でお使いいただくために、本機内部のファームウェア(制御プログラム)を更新する場合があります。
- この取扱説明書に記載の画面イラストは、実際に表示される画面と異なる場合があります。チャンネル番号、チャンネル名、番組名などを含め、実際に表示される内容については画面でご確認ください。
- 本機の仕様および機能などは、ダウンロードなどにより予告なく変更することがあります。
- この取扱説明書と製品保証書は、大切に保管してください。製品保証書は、本製品を修理する場合など、当社のサポートをお受けいただく際に、ご提示いただく必要があります。
- 本製品に関するお問い合わせ、および修理に関しましては、お買い上げになった販売店、または、当社テクニカルセンターまでご連絡ください。
- この取扱説明書の内容につきましては、将来予告なしに変更することがあります。最新の情報についてはテクニカルセンターまでお問い合わせください。
- この取扱説明書の内容につきましては、万全を期して作成しておりますが、万が一、誤りや記載もれなどがございましたらテクニカルセンターまでご連絡ください。

ファームウェアの更新について

ファームウェアデータは、地上デジタル放送波にファームウェア信号を載せて送信され、本機へデータをダウンロードします。ファームウェアの更新は、本機の電源が切られているとき(電源インジケータが赤色点灯時)に自動的に実行します。また、ファームウェアの更新処理には約10分かかります。長期間ご使用にならないとき以外は電源コードを抜かないようにしてください。

デジタル放送の種類と特徴

本機は以下の3種類のデジタル放送を受信することができます。アナログ放送(地上放送、衛星放送、CATV放送)は受信できません。

地上デジタル放送

2003年12月から関東、中京、近畿の三大広域圏の一部で開始され、2006年末までにその他の都道府県の県庁所在地で開始された、地上波のUHF帯を使用したデジタル放送です。

○これまでの地上アナログ放送と比べて、以下の特徴があります。

●デジタルハイビジョン放送を中心とした高画質放送

●高音質放送、マルチチャンネルのサラウンド放送

●ゴーストのない鮮明な映像

●電子番組表(EPG)

放送電波で送られる番組情報で画面に番組表を表示させ、視聴番組を選んだり録画予約をしたりすることができます。

●天気予報や番組案内などのデータ放送、番組に連動したデータ放送、視聴者参加型の双方向サービス

通常の番組に加えて、地域に密着したニュースや天気予報などのデータ放送があります。また、双方向サービスによるオンラインショッピングや、視聴者参加型のクイズ番組などもあります。

○受信にはUHFアンテナを使用します。

従来のUHF放送受信に使用していたUHFアンテナをそのまま使用できる場合と、交換または調整が必要な場合があります。

○本機は「CATVパススルー対応」です。

ケーブルテレビ局が再送信する地上デジタル放送を受信することができます。

BSデジタル放送

デジタル方式の放送衛星(Broadcasting Satellite;通称BS)を使用したデジタル衛星放送です。

○地上デジタル放送と同様の特徴のほかに、以下の特徴があります。

●日本全国どこでも同じ放送が楽しめます

●一部に視聴契約が必要な有料チャンネルがあります

●2種類のデータ放送(運動データ放送、独立データ放送)や双方向サービスがあります

●ラジオ放送が運用されることがあります

○受信にはBS・110度CS共用アンテナを使用します。

110度CSデジタル放送

BSデジタル放送の衛星と同じ東経110度に打ち上げられている通信衛星(Communication Satellite;通称CS)を利用して、(株)スカイパーフェクト・コミュニケーションズが運用しているデジタル衛星放送です。

○以下の特徴があります。

●さまざまなテレビ番組や専門チャンネル、データ放送などの多彩な放送があります

●多くのチャンネルで有料の視聴契約が必要で

●ラジオ放送が運用されることがあります

○受信にはBS・110度CS共用アンテナを使用します。

○デジタル放送には以下の4種類の放送フォーマットがあります。

	デジタルハイビジョン放送(HD)		プログレッシブ放送(SD)	通常放送(SD)
放送フォーマット	1080i放送	720p放送	480p放送	480i放送
走査線の数	有効1080本	有効720本	有効480本	有効480本
走査の方式	飛越走査(インターレース)	順次走査(プログレッシブ)	順次走査(プログレッシブ)	飛越走査(インターレース)
画面サイズ	16:9	16:9	16:9	16:9、4:3

デジタルハイビジョン放送1番組と通常放送3番組程度を、時間帯によって切り換えて放送するマルチチャンネル放送もあります。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続


調整と設定

その他

各部の名称(本体)


本体前面

- 1 液晶画面
- 2 リモコン受光部・電源ランプ
- 3 スタンド




本体背面

- 1 端子部
- 2 電源コード
- 3 ビデオ入力
- 4 HDMI入力
- 5 光デジタル音声出力
- 6 USB端子 (録画用)
- 7 LAN端子



- 1 チャンネル切替ボタン
- 2 音量ボタン
- 3 放送切替ボタン
- 4 入力切替ボタン
- 5 電源ボタン



ご利用前に

テレビを見る準備

基本の操作


外部機器との接続

調整と設定

その他

各部の名称(本体)

本体左側面端子部



ご利用前に

テレビを見る準備


基本の操作

外部機器との接続

調整と設定

その他

各部の名称(リモコン)



1 電源ボタン

テレビの電源を入れたり、切ったりします。

2 入力切替ボタン

入力ソースを切り換えます。入力切替ボタンを押すたび、入力が切り換わり自動的にその画面が表示されます。

3 数字ボタン

視聴するチャンネルを選択します。また、英数字・記号等の入力に使用します。

4 CS ボタン

110度CSデジタル放送に切り換えます。

5 静止ボタン

映像画面のみを静止します。

6 d データボタン

データ放送を表示します。

7 音声切替ボタン

2 カ国語 / ステレオなど音声を切り換えます。

8 消音ボタン

音声を一時的に消します。もう一度押すと消音を解除します。

9 メニューボタン

メニュー画面を表示します。

10 戻るボタン

メニュー画面を表示しているとき、1つ前の画面に戻ります。

11 決定ボタン

メニュー画面の選択内容を決定します。

▲▼◀▶ ボタン

メニュー画面を表示しているときはカーソルを移動します。

12 3桁入力ボタン

3桁の番号を入力するときを使用します。

13 地デジボタン

地上デジタル放送に切り換えます。

14 字幕ボタン

字幕を切り換えます。

15 画面表示ボタン

現在受信しているチャンネルの番組情報が表示されます。

16 チャンネル へ▼ ボタン

チャンネルを順に切り換えます。

17 音量 + / - ボタン

音量を大きくしたり、小さくしたりします。

18 BS ボタン

BSデジタル放送に切り換えます。

19 カラーボタン(青、赤、緑、黄)

データ放送を利用する場合に使用します。

20 終了ボタン

メニュー画面、入力切替、画面表示、番組表を消したときに押します。

21 番組表ボタン

番組表をテレビ画面に表示します。

各部の名称(リモコン)



22 録画リスト

TVモード:録画リストを表示します。

23 画面サイズ

番組説明の表示を切り換えます。

24 番組説明ボタン

番組説明の表示を切り換えます。

25 再生ボタン

USBハードディスクに録画した番組を再生します。

26 停止ボタン

USBハードディスクに録画した番組の再生を停止します。

27 録画ボタン

TV視聴中に押すと、番組を録画します。
(USBハードディスクを接続している時)

28 一時停止ボタン

再生を一時停止します。

29 早戻しボタン

再生中に押すと、早戻し再生をします。

30 早送りボタン

再生中に押すと、早送り再生をします。

31 バックボタン

再生中に前のトラックに進みます。

32 スキップボタン

再生中に次のトラックに進みます。

スタンドの取り付け

ご利用前に


テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他



ご使用前に、スタンドを取り付けてください。スタンドは2つあります。本体にスタンドを取り付ける際は、左の図を参照し正しく取り付けてください。


- 1 テーブルなどの台の上に毛布などのやわらかい布を敷き、その上に液晶画面を下向きにして本機を置く
- 2 本体にスタンドを固定する穴の位置を合わせ、付属のネジ4本で固定します。

ご注意


液晶パネルを傷つけないよう取り扱いにご注意ください。

リモコンの準備と使い方


1 リモコン裏側の電池ケースカバーを上方 向へ引き、カバーをはずす



2 乾電池の+、-極の方向に注意して電池 ボックスに乾電池を入れる



3 電池ケースカバーを元に戻す



ご注意


新しい乾電池と古い乾電池を混ぜて使わないでください。新しい乾電池の寿命が短くなります。古い乾電池から化学液が漏れることがあり、火災やけがの原因になります。乾電池の入れ方が正しくないとリモコンの故障の原因になり、火災につながる恐れがあります。

お願い

乾電池は正しい電極の向きで入れてください。乾電池の廃棄は、自治体の条例または規則に従ってください。長時間リモコンを使用しない場合は、乾電池を取りはずし、正しく保管してください。

リモコンで操作できる範囲

本体前面のリモコン受光部の正面から約7メートル、左右30°の範囲でお使いください。



お願い

• 本体とリモコン受光部の間に物を置かないでください。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

アンテナを接続する

ご利用前に



テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他




ご注意

- アンテナを接続するときは、必ず本機およびすべての接続機器の電源プラグを抜いた状態で行ってください。
- アンテナ工事は技術と経験が必要ですので、アンテナの設置や調整については販売店にご相談ください。
- 一部のアンテナプラグの形状は、アンテナ端子への挿入が困難な場合があります。アンテナプラグをご確認ください。

UHFアンテナ線のつなぎかた

地上デジタル放送はUHF帯が利用されています。UHF対応のアンテナを使用してください。VHFアンテナでは受信ができません。現在お使いのアンテナがUHF対応であっても地域やアンテナ設置状況によっては取り替えや調整、またはブースターの追加などが必要になることがあります。アンテナや接続に必要なアンテナ線(同軸ケーブル)などは付属しておりません。ご使用のアンテナの種類や使用環境条件に合わせて適切な市販品を別途お買い求めください。



お知らせ

- 受信信号レベルは天候等の影響により変動いたします。34ページを参照頂きレベルが50以上になるように設定してください。レベルが足りない場合はブースター等で調整してください。
- ケーブルテレビで放送を受信している場合は、契約されているケーブルテレビ会社にお問い合わせください。

アンテナを接続する(つづき)

BS・110度CSデジタル用アンテナ線のつなぎかた

- BSデジタル放送だけを視聴する場合はBSデジタル用アンテナを、110度CSデジタル放送も視聴する場合はBS・110度CSデジタル用アンテナをご使用ください。(以下、これらのアンテナをBS・110度CSデジタル用アンテナと記載します)
- 本機とBS・110度CSデジタル用アンテナの接続には、BS・CSデジタル対応のケーブル(S-4C-FB相当)をご使用ください。
- 110度CSデジタル放送を受信する場合でブースターやBS・CS分配機を使用する場合は、110度CSデジタル放送(周波数2150MHz以上)に対応したものをお使いください。対応していないものを使用した場合には、110度CSデジタル放送を受信できません。


お知らせ

- 受信信号レベルは天候等の影響により変動いたします、34ページを参照頂きレベルが50以上になるように設定してください。レベルが足りない場合はブースター等で調整してください。

ご注意


- 本機のBS・110度CSアンテナ入力端子からBS・110度CSアンテナに電源が供給されます。ケーブルにF型コネクターを取付加工する場合は、芯線とアース線がショートしないようにしてください。

BS・110度CSデジタル用アンテナをつなぐとき




BS・110度CSデジタル用アンテナ1台で、本機などBSや110度CS機器を2台以上つなぐ場合

- BSや110度CS機器をつなぐときは、BSや110度CS機器付属の取扱説明書をご覧ください。
- 将来、110度CSデジタル放送でチャンネルがふえた場合、ご使用のアンテナによっては分配器は使用できないことがあります。



B-CASカードを入れる／電源を入れる


B-CASカードを入れる



ご注意

B-CASカードの抜き差しは、本機の電源プラグをコンセントから抜いた状態で行ってください。

miniB-CASカードの紛失防止のため、付属のminiB-CASカバーを取り付けてご使用ください。




B-CASカードのお問い合わせについて

B-CASカードのお問い合わせは、下記をお願いします。

株式会社 ビーエス・コンディショナルアクセスシステムズ
カスタマーセンター
TEL:0570-000-250

電源を入れる

1 電源プラグをコンセントに差し込む



2 本体の電源ボタンを押す

電源が入り、本体前面の電源ランプが緑色に点灯します。画面が表示されるまでにしばらく時間がかかります。はじめて電源を入れたときはチャンネル設定が必要です。次ページの「はじめての設定」に進んでください。

お知らせ

電源を入れてから画面が表示されるまでに約10秒程度時間がかかります。本機には、クイックスタート(高速起動)機能がごございます。クイックスタートの設定は4.4ページをご参照ください。

ご注意

本体の電源ボタンで電源を切っているときは、リモコンで電源を入れることはできません。
※電源が「切」の状態では、「電源」のLED表示が消灯します。この状態では、番組表のデータ受信、ソフトウェアのダウンロードなどを行なうことが出来ません。

なお長期ご使用にならない場合を除き、リモコンにて電源の「入」「切」操作を行っていただきますようお願い致します。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他


チャンネル設定をする

はじめての設定


お買い上げ後、B-CASカードを入れてはじめて電源を入れたときは、「はじめての設定」を行います。お住まいの地域に適したチャンネル設定をしてください。

1 表示に従って、**決定**を押す

「はじめての設定」画面が表示されます。




2 ▲▼◀▶でお住まいの地方を選んで、**決定**を押す



3 ▲▼◀▶でお住まいの都道府県を選んで、**決定**を押す


お買い上げ後、B-CASカードを入れてはじめて電源を入れたときは、「はじめての設定」を行います。お住まいの地域に適したチャンネル設定をしてください。



お知らせ

- メニューを表示したまま一定の時間が経過すると、自動的にメニュー表示が消えます。
- 戻る**を押すと、ひとつ前のメニューに戻ります。
- メニュー画面の最下部に、簡易操作ガイドが表示されます。

4 地上デジタルの初期スキャン画面が表示されます。



チャンネル設定をする(つづき)

5 「はい」が選択されているのを確認して、**(決定)**を押す

地上デジタル放送チャンネルの初期スキャンが始まります。終了するまでしばらくお待ちください。



スキャンが終わり「はい」を選んで**(決定)**を押すと、地上デジタル放送チャンネルの設定内容を確認しますか?が表示されます。「はい」を選んで**(決定)**を押します。

序号	チャンネル	放送局
1	テレビ	NHK総合・東京
2	テレビ	NHK Eテレビ東京
3	テレビ	t v k
4	テレビ	日本テレビ
5	テレビ	テレビ朝日
6	テレビ	TBS

Buttons at the bottom: **▶▶** でページ切換 **決定** で次へ進む


6 ▼を押して、チャンネルの設定結果を確認する

お知らせ

- 自動設定された内容を変更したい場合は、「地上デジタル手動設定」で設定しなおすことができます。(46ページ参照)
- 地域によっては地上デジタルのチャンネルの設定番号が変更になる場合があります。その地域にお住まいの方はチャンネル再スキャンをしてください。(46ページ参照)


○郵便番号の設定

お住まいの地域に密着したデータ放送(天気予報・選挙速報など)を視聴したりするための設定です。郵便番号を設定することで、地域が指定されます。




7 お住まいの地域の郵便番号を **1 ~ 10/0** で入力し、**(決定)**を押す。

間違えて入力したときは、**◀**でカーソルを戻してからもう一度入力します。郵便番号入力で、上3ケタを入力して **を**を押すと残りの4ケタは自動的に「0」が入力されます。



8 お好みの映像モードを選択して**(決定)**を押す

「はじめの設定 映像メニュー設定」が表示されます。




9 以上ではじめての設定は完了です。

録画機の準備をする

本機に接続したUSBハードディスク(別売り)で、デジタル放送番組の録画や録画予約ができます。

USBハードディスクを接続する

本機背面のUSB端子(録画用)に接続してください。



お知らせ

- 本機に接続できるUSBハードディスクの最大容量は2TBです。
- 本機に接続できるUSBハードディスクについては、71ページをご覧ください。

ご注意

- 本機とUSBハードディスクは、USBケーブルで直接接続してください。USBハブを経由して接続すると、正しく動作しない場合があります。
- パソコンで使用していたUSBハードディスクを本機に接続して登録すると、パソコンなどで保存していたデータはすべて消去されます。
- USBハードディスクの動作中は、USBハードディスクの電源を切ったり、USBケーブルを抜いたりしないでください。保存した内容が消えたり、ハードディスクが故障したりする原因となります。
- 本機に接続し初期化登録を行ったUSBハードディスクは本機以外のテレビやパソコンなどでは利用できません。

新しいUSBハードディスクを登録する

USBハードディスクを初めて接続するときは、必ず初期化をしてください。初期化しないと録画することはできません。

1 以下の操作で「設定の初期化」画面にする

⊙ を押します。

▲▼で「設定」を選び、(決定)を押します。

▲▼で「初期設定」を選び、(決定)を押します。

▲▼で「設定の初期化」を選び、(決定)を押します。

2 ▲▼で「HDDの初期化」を選び、(決定)を押す

3 ◀▶で「はい」を選び、(決定)を押す

初期化が始まります。

4 初期化が完了したら、(決定)を押す

録画機の準備をする(つづき)

USBハードディスクの設定をする

登録したUSBハードディスクの設定の変更、取外しのための設定、動作テストおよび初期化などができます。

1  を押して、「メニュー」→「HDD管理」の順に選ぶ

ダイレクト録画

リモコンの  で、録画を開始したときの録画時間を設定します。

30分、1時間、90分、2時間、3時間、4時間、12時間のの中から選択できます。

出荷時は「2時間」に設定されています。

省エネ設定

本機の電源が「入」のときに、USBハードディスクの電源を常時「入」にしておくか(通常モード)、USBハードディスクを使用しない状態が続いたときは待機状態にする(省エネモード)にするかを設定できます。

お知らせ

「省エネモード」に設定した場合、USBハードディスクが動作するまでに時間がかかることがあります。

HDD取りはずし

本機に接続したUSBハードディスクの電源を切ったり、接続ケーブルを抜くときは、この操作をします。

「HDD取りはずし」を選ぶと、確認画面が表示されるので、「はい」を選びます。

お知らせ

本機に一度登録してから取りはずしたUSBハードディスクは、再度接続したときに自動的に認識します。録画した番組を消去することなく登録できます。

ご注意

本機に接続したUSBハードディスクは、必ずこの操作により安全に取りはずしてください。安全に取りはずしをしなかった場合、次回電源を入れたときに、ハードディスクの認識に数分かかったり、ハードディスクを認識できなくなったりする可能性があります。また、本機の動作が不安定になる場合があります。

HDD動作テスト

本機に接続したUSBハードディスクで、ハイビジョン画質の録画、録画中の再生などができるかをテストします。

「HDD動作テスト」を選ぶと、テストが開始され、テストの結果が問題ない場合は、「HDDは正常に動作しています」と表示されます。

HDD初期化

USBハードディスクを初期化します。

正常に使用できなくなったUSBハードディスクを初期化することで使用できるようになる場合があります。

ご注意

- 初期化すると、USBハードディスクに保存されている内容はすべて消去されます。
- USBハードディスクの初期化中に、本機やUSBハードディスクの電源をオフ(停電等も含む)したり、USBケーブルを抜き差ししたりすると、本機やUSBハードディスクの故障の原因になります。

地デジ難視対策衛星放送を受信する場合

地デジ難視対策衛星放送について

地デジ難視対策衛星放送とは、地上デジタル放送が送り届けられない地区にお住まいの方に、テレビ放送を視聴いただけるように、暫定的に衛星放送を利用して地上デジタル放送の番組をご覧ください。この放送は総務省の補助と放送事業者の負担によって、社団法人デジタル放送推進協会(Dpa)が実施しています。

- 視聴制御(スクランブル)をかけて対象地区を限定した放送です。
- 実施期間が2015年3月末までに限定された放送です。
- 視聴できるのはNHKおよび地域民放と同系列の東京の放送局の番組です。
- 地上デジタル放送と画質や利用できるサービスに違いがあります。(ハイビジョン画質ではなく標準画質となります。データ放送および双方向サービスは利用できません)
- この放送を利用できる対象地区は、総務省のホームページにて公表されています。
http://www.soumu.go.jp/main_sosiki/joho_t-susin/dtv/index.html

ご利用やお申込みについてご不明な点は、以下の窓口にお問い合わせください


地デジ難視対策衛星放送についてのお問い合わせ先

地デジ難視対策衛星放送受付センター
【電話】(通話料がかかります)
0570-08-2200 (045-345-0522)
【受付時間】平日9:00~21:00
土・日・祝9:00~18:00

本機の設定をする

お買い上げ時、本機は地デジ難視対策衛星放送の視聴や番組表表示ができないようになっています。利用できるようにするには、以下の設定が必要です。
「地デジ難視対策衛星放送受付センター」への利用申込手続が完了した時点で視聴などができるようになります。
(手続完了前は設定をしても視聴などはできません)

- 1 ④メニューを押し、▲▼と⑤決定で「設定」⇒「初期設定」⇒「チャンネル設定」⇒「地デジ難視対策衛星放送」の順に進む



- 2 ▲▼で「利用する」を選び、⑤決定を押す

地デジ難視対策衛星放送番組の視聴や番組表表示ができるようになります。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

テレビを見る

ご利用前に


テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他



1 リモコンまたは本体の電源ボタンを押す

前面の電源ランプが緑色に点灯します。しばらくすると、前回見ていたチャンネルが表示されます。

2 地デジ、BS、CS で地上デジタル放送、BS放送またはCS放送を選ぶ

3 数字ボタン(①~⑫)、チャンネル へ ▼ ボタンまたはチャンネル番号を入力してチャンネルを選ぶ

チャンネル へ ▼ チャンネルが順送りに切り換わります。チャンネル番号の入力は、**0** を押し、**▲▼** と **(決定)** で「その他の設定」→「チャンネル番号入力」を選び、数字キーで3桁のチャンネル番号を入力します。(リモコンの[3桁入力]でも可能です。)

4 音量+/-で音量を調節する

音だけを消したいとき

1 (消音) を押す

画面右下に「消音」と表示されます。



2 元に戻すには、もう一度(消音)を押す

音量+/-を押しても音が出ます。

番組表を見る(デジタル放送のみ)

デジタル放送では、放送局から送られてくる番組情報をもとに、新聞や雑誌などのテレビ番組欄のような放送局別の番組一覧を見ることができます。現在から最大7日先までの放送予定を確認できます。

1 デジタル放送視聴中に「番組表」を押す

視聴中のチャンネルの番組表が表示されます。放送の種類を変更するには「地デジ」、「BS」、「CS」のいずれかを押します。



2 番組表を消すには、「戻る」、「番組表」、終了を押す

お知らせ


「番組表」を押すと2秒ほどで表示されます。

Ⓞを押して番組情報取得を選択し、番組情報取得してください。(表示されるまでに時間がかかったり、情報が取得できないことがあります。)

番組表の見かた

5時間分の番組表が表示されます。
▲▼で時間帯が移動します。

6チャンネル分の番組表が表示されます。
◀▶でほかのチャンネルに移動します。



選択している番組枠の情報が表示されます。

視聴予約を設定する

1 デジタル放送視聴中に「番組表」を押す

番組表が表示されます。

2 ▲▼◀▶で予約したい番組表を選び、Ⓞを押す

3 番組説明を確認して、「視聴予約をする」を選び、Ⓞを押す

4 番組表の画面で、予約した番組のボックスに黄色いマークが付く

ご注意

視聴予約を設定後、電源を切ると予約は取り消されます。

視聴予約を取り消す

1 予約した番組を選び、Ⓞを押す

2 番組説明を確認して、「視聴予約を取消」を選び、Ⓞを押す

3 番組表の画面で予約した番組のボックスの黄色いマークが消える

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

デジタル放送の便利な機能を使う

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

字幕を表示する

字幕のある番組のときに、字幕の表示・非表示を切り換えることができます。

1 デジタル放送視聴中に [字幕] を押す

「字幕オフ」「日本語字幕」を選択します。

文字スーパーを表示する

文字スーパーは、見ている番組とは連動せずに速報ニュースなどを表示するものです。文字スーパーの表示は、メニューの「文字スーパー表示設定」から設定することができます。48ページをご参照ください。

降雨対応放送に切り替える

BSデジタル放送、110度CSデジタル放送を視聴中に、雨や雪などで衛星からの電波が弱まったときには、放送局が運用していれば、降雨対応放送に切り替えて見ることができます。

※以下のメッセージが表示された場合は、降雨対応放送に切り替えてください。

1 を押す

2 ▲▼で「その他の設定」を選び、 を押す

3 ▲▼で「信号切替」を選び、 を押す

4 ▲▼で「降雨対応放送切替」を選び、 を押す

4 ▲▼で「降雨対応放送」を選ぶ

降雨対応放送をやめるには、「通常の放送」を選んでください。

チャンネル情報を見る／音声を切り換える

チャンネル情報を見る

画面表示ボタンを押すと、現在受信中のチャンネル番号・音声情報・映像情報などが表示されます。

1  を押す

2 表示を消すには、もう一度  を押す

地上デジタル放送の場合

チャンネル番号、放送局名、現在時刻、番組名、放送時間などが表示されます。



…録画しているチャンネルには赤丸が表示されます。

しばらくすると、画面下部の表示は消えて上部の表示だけになります。



…録画しているチャンネルには赤丸が表示されます。

音声を切り換える

1  を押す
押すたびに別の音声に切り換わります。

地上デジタル放送の場合



お知らせ

受信している放送によって音声表示は異なります。切り換える音声がない場合には「音声多重放送でないため、切り換えられません。」と表示されます。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

データ放送を見る

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

データ放送とは？

デジタル放送には映像や音声による通常のテレビ放送以外に、データ放送があります。データ放送には、テレビ放送チャンネルとは独立した別のチャンネルで行われているデータ放送のほかに、テレビ放送チャンネルで提供されている番組連動データ放送や、番組案内、ニュース、天気予報などのデータ放送があります。

ラジオ、独立データ放送を楽しむ

- 1 デジタル放送を見ているときに、を押す
- 2 ▲▼で「その他の設定」を選び、を押す
- 3 ▲▼で「テレビ／ラジオ／データ切換」を選び、を押す
- 4 切り換えたい項目「テレビ」「ラジオ」「データ」を選び、を押す

連動データ放送を楽しむ

テレビ放送チャンネルで、天気予報やニュース、番組案内などのデータ放送を提供している場合があります。

- 1  ボタンを押す
放送局により、表示される内容が異なります。画面に表示される操作指示に従って操作してください。
- 2 ▲▼◀▶で移動し、 ボタンを押す
選択した情報を見ることができます。
- 3  ボタンを押すと、通常の画面に戻ります
 を押し、▲▼と  で「その他の設定」→「データ放送終了」を押しても終了します。

お知らせ

- 放送データの取得中は、一部の操作ができないことがあります。
- 放送画面の操作説明などで、[dデータ]ボタンは「データボタン」「データ放送ボタン」と表示される場合があります。
- 本機は、電話回線を利用した双方向サービスには対応していません。

画面サイズを変える

画面サイズを変える

視聴している番組に適した画面サイズを選ぶことができます。

地上デジタル放送の16:9映像のとき

1 リモコンの「画面サイズ」ボタンを押す
(もしくは  を押し、「画面サイズ切替」を選択し、 を押す)


2 画面サイズ切替が表示されます



3 「ワイド」「ズーム」「フル」を選んで、 を押す


ワイド

左右に黒帯のある画像を、画面いっぱいに拡大して表示します。(上下の映像が画面の外に隠れ、横伸びします)




ズーム

上下左右に黒帯のある映像を画面いっぱいに表示します。



フル

16:9の映像をそのままのアスペクト比で表示します。



画面の位置や幅を調整する

画面右下に表示されている「放送／端子、信号、画面サイズ」の組み合わせごとに、「画面調整」の調整状態が記憶されます。

ご注意

- 「画面サイズ切替」が「フル」の場合は調整できません。
- 映像の種類と画面サイズによっては、調整できない場合があります。

1  を押す

2 ▲▼で「設定」を選び、 を押す

3 ▲▼で「機能設定」を選び、 を押す

4 ▲▼で「画面調整」を選び、 を押す

5 ▲▼で調整したい項目を選び、 を押す

○ 上下振幅調整

映像の縦のサイズを調整します。

○ 上下画面位置

映像の表示位置を上下に調整します。

○ 左右振幅調整

映像の横のサイズを調整します。

6 ◀▶でお好みの状態に調整し、 を押す

上下振幅調整と左右振幅調整は-03～+03、上下画面位置の表示位置は-10～+10の範囲で調整できます。

調整画面は◀▶を押さないで数秒でメニュー画面に戻ります。

録画・予約をする

録画機能について

USBハードディスクに録画できる番組

番組	録画の可／不可
地上デジタル放送番組	録画できます
BS/110度CSデジタル放送番組	録画できます
外部入力からの映像・音声	録画できません

ご注意

- 録画できるのは本機で受信した放送番組です。データ放送の内容は録画できません。

USBハードディスクの接続・設定と録画前の準備

接続・設定

- 22ページ

録画前の準備

- USBハードディスクと本機を接続しておきます。
- 残量不足や番組数超過になりそうな場合は、不要な番組を削除してください(36ページ)

ご注意

- 本機に登録していないUSBハードディスクでは録画できません。
- 録画や録画予約の操作をしたときに接続した機器が選択できない場合は、上記ページを参照し、接続・設定を確認してください。
- 本機で動作確認済みのUSBハードディスクについては、71ページを参照してください。

音声を切り換える

録画・予約の種類

録画・予約の種類	記載ページ
見ている番組を録画する	46ページ
番組表から録画予約する	46ページ
連続ドラマなどを繰り返し録画予約する	46ページ
録画する日時を指定して録画予約する	47ページ

ご注意

- 最大予約件数は64件です。また、最大総番組数は300件です。
- 本機に接続したUSBハードディスクは、容量に関わらず、残容量が1GB未満もしくは1%未満になった場合は録画できません。
- 録画中に、本機やUSBハードディスクの電源をオフ(停電等も含む)したり、USBケーブルを抜き挿ししたりすると、本機やUSBハードディスクの認識不良、録画番組が消去されるなど、本機の動作に不安定になる場合があります。
- 録画中に停電したり、電源プラグを抜いたりすると、途中で録画した番組は残りません。

重要なお知らせ

万一、本機の故障や故障による修理、受信障害などによって録画・録音・録画データの再生が出来なくなった場合の保証は一切できませんので、あらかじめご了承ください。

録画・予約をする(つづき)

その他の録画機能について

USBハードディスクの自動削除機能について

- 録画番組数が300件を超える場合や、ハードディスクの残容量が1GB未満もしくは1%未満になった場合に、録画開始時に自動的に録画番組を削除する機能です。録画日付の古い順に、再生済みの番組が自動的に削除されます。再生済みの番組を削除してもハードディスクの残容量が不足しているときは、録画日付の古い順に、保護していない番組が削除されます。
- お買い上げ時には、USBハードディスクの「自動削除設定」(36ページ)が「削除する」に設定されています。
- 録画番組が自動的に削除されないようにする場合は、「自動削除設定」を「削除しない」に設定するか、または録画番組を保護してください(36ページ)。

録画可能時間の目安

「自動削除設定」が「削除する」に設定されている場合、録画時間が下表の時間よりも少なくなることがあります。

例:500GBのUSBハードディスクの場合

放送番組の種類	録画可能時間の目安
地上デジタルハイビジョン放送(HD)番組だけを録画する場合	約50時間
BS/110度CSデジタルハイビジョン放送番組(HD)だけを録画する場合	約42時間
地上デジタルおよびBS/110度CSデジタルの標準テレビ放送番組(SD)だけを録画する場合	約125時間

- USBハードディスクの残量時間表示は、BSデジタル放送のHD放送(24Mbps)を基準に算出しています。録画可能時間表示はあくまでも目安としてご確認ください。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

録画・予約をする(つづき)

見ている番組を録画する

現在視聴しているデジタル放送番組を録画します。

1 を押す

見ている番組の録画が始まります。
お買い上げ時は、2時間後に録画が自動的に停止します。録画時間の設定を変更する場合は、22ページをご覧ください。

番組表から録画予約する

1 を押す

2 で録画したい番組を選び、 を押す

3 以下の操作で録画・予約をする

現在放送中の番組を選んだ場合



で「録画をする」を選び、 を押す
録画予約登録確認画面が表示されます。

これから放送される番組を選んだ場合



で「録画予約をする」を選び、 を押す
録画予約登録確認画面が表示されます。

4 を押す

「予約を設定しました。」が表示されたら、決定を押します。
これで録画予約は完了です。番組表に録画予約アイコンが表示されます。

お知らせ

- 地上デジタル放送で番組編成の変更があった場合、予約どおりに動作しないことがあります。
- 複数の番組が連続して予約されている場合、番組の最後の部分が録画されません。
- 予約の確認や取消しについては、33ページをご覧ください。

連続ドラマなどを繰り返し録画予約する

連続ドラマなど同じ時間帯に繰り返し放送される番組を、毎回自動的に録画することができます。

1 を押す

2 で繰り返し録画予約したい番組を選び、 を押す

3 で「録画予約をする」を選び、 を押す

4 でお好みの設定を選び、 を押す

設定項目は以下のとおりです。
「月～木」「月～金」「月～土」「毎日」「毎週(月)～」「毎週(日)」

5 で「はい」を選び、 を押す

繰り返し録画予約が設定されます。

録画・予約をする(つづき)

録画する日時を指定して録画予約する

- 1 **番組表** を押す
- 2 **メニュー** を押す
メニューが表示されます。
- 3 **▲▼** で「予約リスト」を選び、**決定** を押す
予約リストが表示されます。
- 4 **青** を押す
日時指定予約画面が表示されます。
- 5 録画予約の日時を設定する
 - ① 設定する項目を **◀▶** で選び、**▲▼** で日時設定する
 - 6週間先まで指定できます。
 - 特定の日のほかに、「毎日」「毎週(月)」～「毎週(日)」、「月～木」、「月～金」、「月～土」などの繰り返し録画も選べます。
 - 設定できる時間は最大12時間です。
 - ② 設定が終わったら、**決定** を押す
- 6 録画するチャンネルを設定する
 - ① 設定する項目を **◀▶** で選び、**▲▼** で内容を選ぶ
 - 放送の種類……地デジ/BS/CS
 - 放送メディア…テレビ/ラジオ(BS・110度CSのみ)/データ
 - チャンネル……指定された放送の種類やメディアに該当するチャンネル
 - ② 設定が終わったら、**決定** を押す
- 7 **▲▼◀▶** で「録画予約」を選び、**決定** を押す
- 8 「予約を設定しました。」が表示されたら、**決定** を押す

録画を中止する

録画を途中でやめるときは、以下の操作をします。
ハードディスクの残量がなくなった場合は録画が自動的に停止します。

見ている番組を録画中のとき

- 1 **停止** を押す
録画が停止します。

録画予約で録画中のとき

- 1 **停止** を押す
録画の中止を確認するメッセージが表示されます。
- 2 **◀▶** で「はい」を選び、**決定** を押す
録画が停止します。

予約の確認・取消しをする

録画予約した内容の確認、取消しができます。


- 1 **番組表** を押す
- 2 **メニュー** を押す
メニューが表示されます。
- 3 **▲▼** で「予約リスト」を選び、**決定** を押す
予約リストが表示されます。
- 4 **▲▼** で予約を確認する番組を選び、**決定** を押す
この画面で予約の確認ができます。
- 5 予約を取り消すときは **◀▶** で「はい」を選び、**決定** を押す
予約が取り消されます。

録画・予約をする(つづき)

録画動作について


録画予約した番組の放送時間が連続する場合

録画予約Aが10:00~11:00、録画予約Bが11:00~12:00の場合、録画予約Ano終端10秒間は録画されません。




録画予約した番組の放送開始時刻が同じ場合

録画予約Aと録画予約Bの放送開始時刻がまったく同じ場合、最後に予約された録画予約Bが優先されます。



録画予約した番組の放送時間が一部重複する場合


録画予約Aと録画予約Bの一部の時間帯が重複する場合、開始時刻が早い録画予約Aが優先され、録画予約Aの録画終了後、録画予約Bの録画を開始します。



録画予約した番組が編成変更した場合の動作について

録画予約した番組の放送開始時刻が変更され、他の録画予約と重複した場合

録画予約Aの放送開始時刻が遅延し、録画予約Bの録画中の時間帯に変更された場合、録画を開始している録画予約Bが優先され、録画予約Bの録画終了後、録画予約Aの録画を開始します。




録画予約した番組の放送時間が延長された場合

放送時間延長分も含めて、すべて録画されます。



録画予約した番組の放送時間が延長し、録画予約した次の番組の開始時刻が変更された場合


録画予約Aの放送時間が延長し、録画予約B(Aと同チャンネル)の開始時刻が変更された場合、放送時間延長分も含めて、すべて録画されます。



録画予約した番組の開始時刻時間が変更され、他の録画予約と時間帯が重複した場合

録画予約Aの放送時間が延長し、録画予約B(Aと同チャンネル)の開始時刻が変更された場合、放送時間延長分も含めて、すべて録画されます。

ただし、放送時間帯が重複した録画予約C(他チャンネル)は録画されません。



録画した番組を再生する

録画番組を再生する

USBハードディスクに録画・保存されている番組を見るには、以下の操作をします。

再生の基本操作

1 を押す

録画リストが表示されます。録画リストには、選択している番組の簡単な情報や、録画可能時間、USBハードディスクの残量(%)などが表示されます。

2 ▲▼ で見たい番組を選び、 を押す

- 選んだ番組の再生が始まります。(再生されるまでに時間がかかる場合があります。)
- 番組冒頭部分の4秒間を飛ばして再生が始まりますが、故障ではありません。
- 番組の最後まで再生が終わると、そのまま静止状態になり、しばらくすると録画リストに戻ります。
- 再生中にできるリモコン操作については、36ページを参照してください。

3 再生を停止させるには、 を押す

- 録画リストの画面に戻ります。
- 録画番組の再生を終了するときは、終了を押すか、または選局の操作などをします。

ご注意

- 電源を入れた直後はUSBハードディスクの認識に時間がかかることがあり、すぐに録画リストが開かない場合があります。その場合は、しばらく待ってから再度録画リストを開いてください。
- USBハードディスクに録画した番組は、録画時間が15秒未満の場合は再生できません。次回電源を入れたときに、15秒未満の録画番組は自動的に削除されます。
- 本機で録画した番組は、本機でのみ再生できます。他のテレビ(同じ形式のテレビも含む)では再生できません。
- USBハードディスクに録画した番組を再生中に、本機やUSBハードディスクの電源を切ったり(停電等も含む)、USBケーブルを抜き指したりすると、本機やUSBハードディスクの故障の原因になります。USBハードディスクの認識不良、録画番組が消去されるなど、本機の動作が不安定になる場合があります。

続きから再生する—レジューム再生

- 1 再生する番組を選び、 を押す
前回、再生を途中で停止した場合は、続きから再生されます。

番組の冒頭から再生する—頭出し再生


- 1 再生する番組を選び、 を押す
- 2 「頭出し再生」を選び、 を押す

録画中の番組を再生する—追っかけ再生

録画が終了するまで待たずに、録画中の番組の冒頭から再生します。

- 1 録画中の番組を選び、 を押す

録画番組の再生中にできるリモコン操作



ボタン	内容
	録画番組の再生を開始します。
	再生中に押すと、一時停止になります。一時停止中にもう一度押すと、再生が再開されます。
	再生を停止し、録画リストに戻ります。
	早送り再生をします。(押すたびに速さが変わります)
	早戻し再生をします。(押すたびに速さが変わります)
	再生中に押すと、10分ほど先に進んで再生します。
	再生中に押すと、10分ほど戻って再生します。
	再生中に押すと、録画リストが表示されます。

録画した番組を再生する(つづき)

録画番組の情報や番組説明を見る

- ①再生中に^青 [画面表示] を押す
再生中の番組の情報が表示されます。
- ②表示を消すには、もう一度 [画面表示] を押す

録画した番組を保護する

録画した番組を誤って削除しないように保護することができます。

※録画中にこの操作はできません。

- 1  を押す

- 2 ▲▼で保護する番組を選び、○を押す
または、^{マニ} を押して▲▼で「保護設定」を選び、▲▼で「保護する」を選び、^{決定} を押す

○選択した番組が保護されます(【鍵マーク】がつきます)

○保護されている番組を選び、○を押すと、「保護解除」することができます。

録画した番組を削除する

- 1  を押す

- 2 ○を押す

タイトルの左側にチェックボックスが表示されます。ただし、保護されている録画番組には表示されません。保護されている録画番組を消すには、保護を解除してから○を押してください。

- 3 ▲▼で削除する番組を選び、^{決定} を押す

選んだ番組のチェックボックスにはチェックマークが付きます。削除するすべての録画番組にチェックマークを付けてください。

- 4 ○を押す

- 5 確認画面で◀▶で「はい」を選び、^{決定} を押す

- 6 削除が終了したら^{決定} を押す

自動的に消す(自動削除設定)

お買い上げ時は、ハードディスクの容量が足りなくなったときに、保護されていない古い録画番組が自動的に削除されるように設定されています。削除されないようにする場合は「削除しない」に設定してください。

- 1  を押す

- 2 ^{マニ} を押して▲▼で「自動削除設定」を選び、決定を押す

- 3 ▲▼「削除する」または「削除しない」を選び、決定を押す

お知らせ


録画リストについて

録画開始直後の番組は、録画リストに表示されるまで少し時間がかかります。

録画リストに表示できる最大数は300番組までです。

再生機器を接続する

接続方法映像画質の違いについて



DVDプレーヤーやビデオカメラ、ゲーム機などのAV機器を接続して、本機で楽しむことができます。高精細、高画質に対応した出力端子に接続するとよりきれいな映像が楽しめます。接続する機器の出力端子に応じて、最適な映像端子をお選びください。

お知らせ

本機には接続に使用するケーブル類は付属しておりません。外部機器を接続する際は、あらかじめ必要なケーブル類をご確認の上、お客様にてご用意ください。


外部機器を接続する際のご注意

接続する機器の取扱説明書もよくお読みください。

接続の際は、必ず本機および接続する機器の電源を切り、電源プラグをコンセントから抜いてください。プラグは奥まで完全に差し込んでください。差し込みが不完全だと、ノイズが発生する原因となります。

HDMI端子を使う場合

HDMI端子のあるブルーレイDVDプレーヤー、ケーブルTVや衛星放送のセットトップボックスなどを本機に接続することができます。HDMIケーブルを1本接続するだけで、デジタル信号のまま映像信号と音声信号を入力することができます。



お知らせ

HDMIの標準技術規格に対応した機器をお使いください。

ご利用前に

テレビを見る準備

基本の操作


外部機器との接続

調整と設定

その他

再生機器を接続する(つづき)

映像端子を使う場合



オーディオ機器を接続する

ミニコンポなどの音響システムにつなぐとき


- 本機の音量を最小に調整し、ミニコンポなどの音響システム側で音量を調節してご使用ください。
- 音響システム側が対応しているデジタル音声入力に従って、39ページの「光デジタル音声出力の設定」をします。

サンプリングレートコンバーターを内蔵したMDレコーダーやDATにつなぐとき

- MDレコーダーやDATの光デジタル音声入力端子につなげば、高音質で録音して楽しむことができます。
- 39ページの「光デジタル音声出力の設定」で「PCM」を選択します。

MPEG-2 AACデコーダーにつなぐとき

- デジタル放送のMPEG-2 AAC方式の信号を、MPEG-2 AACデコーダーで楽しむことができます。
- 39ページの「光デジタル音声出力の設定」で「デジタルスルー」または、「サラウンド優先」を選択します。



ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

再生機器を接続する(つづき)

光デジタル音声出力の設定

光デジタル音声出力端子から出力する音声信号を設定します。


お買い上げ時は「PCM」に設定されています。

MPEG-2 AACデコーダーやAACデコーダー内蔵アンプをつなぐときは「デジタルスルー」または「サラウンド優先」に設定してください。


1 以下の操作で「音声設定」画面にする

Ⓞ を押します。

▲▼で「音声設定」を選び、Ⓞ を押します。



2 ▲▼で「光デジタル音声出力」を選び、Ⓞ を押す



3 ▲▼で信号を選び、Ⓞ を押す

PCM

リニアPCM信号が出力されます。

デジタルスルー


MPEG-2 AAC信号の場合、その信号が出力されます。

サラウンド優先

MPEG-2 AAC信号で、サラウンド音声(5.1chや4.1chサラウンド音声など)の場合には、それらの信号が出力されます。それ以外の場合にはリニアPCM信号が出力されます。

パソコンを接続する

本機にHDMI端子のあるパソコンを接続して、本機の液晶画面をパソコンのモニターとして使うことができます。



ご注意

- PCから音声を出力したいときは、PCと本機のHDMI1音声入力端子を接続してください。
- 接続するパソコンの取扱説明書をご覧ください。
- 対応出力フォーマットは、接続するパソコンの仕様をご確認ください。
- 1360×768@60Hz、1024×768@60Hz、800×600@60Hz、640×480@60Hzにのみ対応しております。接続するパソコンによっては、内容を正しく表示できない場合があります。
- Dot by Dotには対応しておりません。適正解像度でも若干のにじんだ表示になる場合があります。

お知らせ

- パソコンを接続する前に、パソコンの画面設定(解像度、周波数)は取扱説明書の仕様を確認し、表示できる設定に変更してください。
- パソコン接続時の表示設定は、自動調整で最良に近い状態に設定されます。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

HDMI連動設定

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

1 以下の操作で「HDMI連動設定」画面にする

メニューを押します。


▲▼で「設定」を選び、決定を押します。

▲▼で「CEC設定」を選び、決定を押します。

「HDMI連動設定」を選び、決定を押します。



2 設定する項目を▲▼で選んで決定を押し、表の手順で設定する



3 終了を押して、メニューを押す

項目	説明および操作手順
HDMI連動機能	HDMIの各種連動制御を使用するかどうかを設定します。 ① ▲▼で「使用する」または「使用しない」を選び、決定を押します。
HDMI連動機器リスト	一台以上のHDMI連動機器を接続するとき、一つのHDMI連動機器選択を設定します。 ① ▲▼で形名を選び、決定を押します。 ② 決定を押すと、HDMIの接続を再検出します。
連動機器→テレビ入力切替	連動機器の再生操作をしたときに、本機が自動的に入力切換をして、その機器を選択する機能です。(本機の電源が「入」の場合) ① ▲▼で「連動する」または「連動しない」を選び、決定を押します。
連動機器→テレビ電源	連動機器の電源を入れたときに、本機が自動的に電源を入れます。 ① ▲▼で「連動する」または「連動しない」を選び、決定を押します。
テレビ→連動機器電源オフ	本機の電源を切ったときに、連動機器が自動的に電源を切ります。 ① ▲▼で「連動する」または「連動しない」を選び、決定を押します。

外部入力設定

外部入力スキップ設定

入力切換をするときに、使っていない入力をスキップする(飛び越す)ことができます。

1 以下の操作で「外部入力設定」画面にする

- ① を押します。
- ▲▼で「設定」を選び、(決定)を押します。
- ▲▼で「機能設定」を選び、(決定)を押します。
- ▲▼で「外部入力設定」を選び、(決定)を押します。



2 ▲▼で「外部入力スキップ」を選び、(決定)を押す



3 設定する外部入力を▲▼で選び(決定)を押す

(決定)を押すたびに「スキップ」が「する」、「しない」に交互に切り替わります。

HDMI 1 音声入力設定

HDMI 1 入力端子を使用しているときは、HDMI 1 音声入力端子を使用することができます。音声信号はオート、デジタル、アナログから選択できます。

1 以下の操作で「外部入力設定」画面にする

- ① を押します。
- ▲▼で「設定」を選び、(決定)を押します。
- ▲▼で「機能設定」を選び、(決定)を押します。
- ▲▼で「外部入力設定」を選び、(決定)を押します。



2 ▲▼で「HDMI 1 音声入力設定」を選び、(決定)を押す



3 ▲▼で以下の項目から選び、(決定)を押す

オート ……自動的に音声出力が切り替わります。

デジタル …… HDMI 1 入力端子に映像、音声ともに入力される場合は、この設定にします。

アナログ …… HDMI 1 入力端子につないだ機器の音声を、HDMI 1 音声入力端子から入力する場合は、この設定にします。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

外部入力設定(つづき)

RGBレンジ設定

通常は「オート」でご使用ください。機器のRGBレンジが識別できない場合は、機器の仕様にあわせて設定をしてください。

1 以下の操作で「外部入力設定」画面にする

Ⓜ を押します。

▲▼で「設定」を選び、(決定)を押します。

▲▼で「機能設定」を選び、(決定)を押します。

▲▼で「外部入力設定」を選び、(決定)を押します。



2 ▲▼で「RGBレンジ設定」を選び、(決定)を押す



3 ▲▼で設定するHDMI入力を選び、(決定)を押す

4 ▲▼で以下の設定から選び、(決定)を押す

オート …… 自動識別します。

デジタル …… RGBレンジ0～255の場合に選びます。

アナログ …… RGBレンジ16～235の場合に選びます。

LAN 端子の接続・設定

LAN端子設定

「LAN端子設定」は、LAN端子の接続をした場合に設定します。ご契約のプロバイダーから設定内容の指定がある場合は、それをもとに設定します。

1 以下の操作で「LAN端子設定」画面にする

⊙ を押します。

▲▼ で「設定」を選び、⊙ を押します。

▲▼ で「初期設定」を選び、⊙ を押します。

▲▼ で「通信設定」を選び、⊙ を押します。



2 設定したい項目を ▲▼ で選んで ⊙ を押し、以下の表の手順に従って設定する

3 設定を有効にするには、本体の電源ボタンで電源を切り、もう一度電源を入れる

項目	説明および操作手順
LAN端子設定 IPアドレス端子設定	<p>インターネットに接続するために本機に割り当てられる、固有の番号を設定します。</p> <p>※「IPアドレス自動取得」を「しない」に設定した場合は、「DNS設定」の「DNSアドレス自動取得」は、自動的に「しない」に設定されます。その場合は、DNSアドレスを手動で設定してください。</p> <p>① ▲▼ で「IPアドレス設定」を選び、⊙ を押す</p> <p>② IPアドレスを自動取得できる場合は、◀▶ で「する」を選ぶ IPアドレスを自動取得できないネットワーク環境の場合</p> <p>1) ◀▶ で「しない」を選ぶ</p> <p>2) ▲▼ で「IPアドレス」を選び、□□～□□□□で入力する</p> <p>3) ▲▼ で「サブネットマスク」を選び、□□～□□□□で入力する</p> <p>4) ▲▼ で「デフォルトゲートウェイ」を選び、□□～□□□□で入力する 2)～4)では0～255の範囲の数字(左端の欄は0以外)を4箇所の欄に入力します。</p> <p>▲▼▶ で選び、□□～□□□□で番号入力、◀で訂正、⊙で設定完了。</p> <p>③ ⊙ を押す</p>

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

LAN 端子の接続・設定(つづき)

項目	説明および操作手順
ご利用前に テレビを見る準備 基本の操作	<p>ドメイン名をIPアドレスに置き換える機能を持ち、IPアドレスで特定されているDNSサーバーを設定します。 ※「IPアドレス自動取得」「しない」に設定した場合は、「DNSアドレス自動取得」は自動的に「しない」に設定され、「する」にはできません。DNSアドレスを手動で設定してください。</p> <p>① ▲▼で「DNS設定」を選び、(決定)を押す ② DNSアドレスを自動取得できる場合は、▲▼で「する」を選ぶ DNSアドレスを自動的に割り当てられないネットワーク環境の場合 1) ◀▶で「しない」を選ぶ 2) ▲▼「DNSアドレス(プライマリ)」を選び、□1~□10/4で入力する 3) ▲▼で「DNSアドレス(セカンダリ)」を選び、□1~□10/4で入力する 2)と3)では0~255の範囲の数字(左端の欄は0以外)を4箇所の欄に入力します。 欄を移動するには、◀▶を押します。 ③ (決定)を押す</p>
LAN端子設定(つづき) プロキシ設定	<p>インターネットとの接続時にプロキシ(代理)サーバーを経由する場合に設定します。ご契約のプロバイダーから指定がある場合にだけ設定してください。ここでのプロキシ設定はHTTPに関するものです。</p> <p>① ▲▼で「プロキシ設定」を選び、(決定)を押す ② ▲▼で「使用する」を選び、(決定)を押す ③ ▲▼で「サーバー名」を選び、(決定)を押す ④ サーバー名を入力する 文字入力モードを切換えるには [画面表示] を押し◀▶入力モードを選択し(決定)を押す。 入力できる文字は半角英字/半角数字で、記号は半角です。 ⑤ ▲▼で「ポート番号」を選び、□1~□10/4でポート番号を入力する ⑥ ▲▼で「設定完了」を選び、(決定)を押す</p>
外部機器との接続	<p>MACアドレス</p> <p>ネットワーク上につながっている機器を識別するために本機に割り当てられている番号です。</p> <p>① ▲▼で「MACアドレス」を選び、(決定)を押す ② MACアドレスを確認したら、(決定)を押す</p>
調整と設定 その他	<p>サービス専用</p> <p>インターネットに正しく越族しているかどうかテストします。</p> <p>① ▲▼で「サービス専用」を選び、(決定)を押す ② 結果を確認したら、(決定)を押す</p>

アンテナの方向調整と設定

地上デジタルアンテナレベル


「はじめての設定」をしても地上デジタル放送が正しく受信できなかったときは、お買い上げの販売店などにご相談のうえ、以下の操作でアンテナの方向調整をしてください。

1 以下の操作で「アンテナ設定」画面にする

- メニューを押します。
- ▲▼で「設定」を選び、決定を押します。
- ▲▼で「初期設定」を選び、決定を押します。
- ▲▼で「アンテナ設定」を選び、決定を押します。



2 ▲▼で「地上デジタルアンテナレベル」を選び、決定を押す



3 ◀▶で「伝送チャンネル」を選ぶ

お住まいの地域の地上デジタル放送に使用されている伝送チャンネルを選んでください。

◀▶を押すたびに以下のように切り換わります。

VHF1 ~ VHF12 ↔ UHF13 ~ UHF62 ↔ CATV13 ~ CATV63

4 アンテナをゆっくり動かして、「アンテナレベル」の数値が最大となるように調整する

アンテナレベルの増減に応じて、棒グラフが表示されます。

5 アンテナを固定して、決定を押す


BS・110度CSアンテナレベル

アンテナの方向調整は、お買い上げの販売店にご相談ください。

1 以下の操作で「アンテナ設定」画面にする

- メニューを押します。
- ▲▼で「設定」を選び、決定を押します。
- ▲▼で「初期設定」を選び、決定を押します。
- ▲▼で「アンテナ設定」を選び、決定を押します。

2 ▲▼で「BS・110度CSアンテナレベル」を選び、決定を押す



受信できるアンテナレベルの目安は、BS デジタルが36以上、110度CS デジタルが28以上です。(表示される数値は、受信C/Nを換算したものです)

3 BS または CS を押して、放送の種類(BSまたは110度CS)を選ぶ

4 契約しているチャンネル、または無料チャンネルを で選ぶ

5 アンテナをゆっくり動かして、「アンテナレベル」の数値が最大となるように調整する

画面のアンテナレベルの最大値を参考に、アンテナを固定したあとにレベル値が下がっていないことを確認してください。

6 アンテナを固定して、決定を押す

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

アンテナの方向調整と設定(つづき)

BS・110度CSアンテナ電源供給

アンテナに供給する電源をアンテナ電源といいます。お買い上げ時は、「供給する」に設定されています。マンションなどで、アンテナに他の機器から電源が供給されているときは、「供給しない」に設定します。

1 以下の操作で「アンテナ設定」画面にする

を押します。

▲▼で「設定」を選び、を押します。

▲▼で「初期設定」を選び、を押します。

▲▼で「アンテナ設定」を選び、を押します。



2 ▲▼で「BS・110度CSアンテナ電源供給」を選び、を押す



3 ▲▼で「供給する」または「供給しない」を選び、を押す

お知らせ

BS・110度CSデジタル用アンテナのアンテナ電源供給設定について本機の電源を入れないで、DVDレコーダー単独で録画するときなどは、本機以外からアンテナ電源を供給する必要があります。

接続した機器の映像を見る(入力切換)

左側面の外部入力端子に接続したDVDプレイヤーやビデオデッキなどの使用時に入力切換を行います。



1 **入力切換** を押す

2 **入力切換** を繰り返し押して、入力モードを選ぶ



お知らせ

- 本体背面の入力切換ボタンでも入力切換ができます。
- 音量の調節は本機のリモコンで行いますが、その他の操作は接続した機器の取扱説明書に従って操作してください。



ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

メニュー画面の操作方法

本機の各種設定を変更することができます。設定できる項目の詳細については、次ページ以降をご覧ください。

例：低音強調の設定をする場合


1 ボタンを押す

メニュー画面が表示されます。




2 ▲▼ で「音声設定」を選んで、 を押す

音声設定メニューが表示されます。



3 ▲▼ で「音声調整」を選んで、 を押す



4 ▲▼ で「低音強調」を選んで、 を押す



6 を押す

メニュー画面が消え、通常の画面に戻ります。

お知らせ

- メニューを表示したまま一定の時間が経過すると、自動的にメニュー表示が消えます。
-  を押すと、ひとつ前のメニューに戻ります。

画面サイズを調整する

画面の位置や幅を調整する

画面右下に表示されている「放送／端子、信号、画面サイズ」の組合せごとに、「画面調整」の調整状態が記憶されます。
※映像の種類と画面サイズによっては、調整できない場合があります。

※パソコンを接続したときに、画面の右下に表示される画面情報とパソコン側で設定した情報が一致しない場合があります。

1 を押す

2 ▲▼で「設定」を選び、を押す

3 ▲▼で「機能設定」を選び、を押す

4 ▲▼で「画面調整」を選び、を押す

5 ▲▼で調整したい項目を選び、を押す

上下振幅調整 …… 映像の縦のサイズを調整します。

上下画面位置 …… 映像の表示位置を上下に調整します。

左右振幅調整 …… 映像の横のサイズを調整します。

6 ◀▶で好みの状態に調整し、を押す

上下振幅調整と左右振幅調整は-03～+03、上下画面位置の表示位置は-10～+10の範囲で調整できます。調整画面では◀▶を押さないと数秒でメニュー画面に戻ります。

画面調整をお買い上げ時の状態に戻す

1 左記の手順5で「初期設定に戻す」を▲▼で選び、を押す

2 ◀▶で「はい」を選び、を押す

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

映像設定メニュー

メニュー画面の「映像設定」を選んで **決定** を押します。



現在選択されている入力モード(テレビ、ビデオ、HDMI、PC)の映像を、お好みの画質に調整できます。

お知らせ

入力モードが「PC」の場合は、選択できない項目があります。

映像メニュー

あらかじめシーンに合わせた映像設定が用意されています。お好みに合わせて設定を切り換えてお楽しみいただけます。



おざやか

日中の明るいリビングで見るときに適した設定です。

標準

落ち着いた雰囲気で見るときに適した設定です。

テレビ

暗くした部屋でテレビ番組を見るときに適した設定です。

映画


暗くした部屋で映画を見るときに適した設定です。

映像調整

映像調整を選択することにより、お好みに合わせて画質調整をすることができます。

調整項目

バックライト、コントラスト、黒レベル、色の濃さ、色あい、シャープネス、詳細調整の各設定を選択します。



バックライト

バックライトの明るさを調整できます。

コントラスト

設定値が低いほど明暗の差が弱まり、設定値が高いほど明暗の差が強調されます。



黒レベル

設定値が低いほど暗く、設定値が高いほど明るくなります。

色の濃さ

設定値が低いと色が薄く、設定値が高いと色が濃くなります。

色合い

設定値が低いと紫っぽく、設定値が高いと緑っぽくなります。

シャープネス

設定値が低いほど輪郭がぼやけ、設定値が高いほど輪郭がくっきり表示されます。

詳細調整

映像をより細かく調整します。詳しくは、55ページをご覧ください。

初期設定に戻す

調整した内容をすべて出荷時の状態に戻します。

映像設定メニュー（つづき）

映像調整・詳細調整

映像をより細かく調整します。

○ノイズリダクション設定

映像のノイズやざらつきを減らします。

ゲーム映像表示のときや、パソコン画面表示のときは設定できません。以下の設定が選べます。

「モスキートNR」:動きの速い映像のブロックノイズとモスキートノイズを減らせます。「強」「中」「弱」「オフ」から選びます。

「3DデジタルNR」:画面のざらつきノイズやちらつきを減らせます。「オート」「強」「中」「弱」「オフ」から選びます。

○ダイナミックバックライト制御

映像の明るさに応じてバックライトの明るさを自動調整し、メリハリのある映像にするかどうかを「オン」「オフ」で選べます。

○シネマスキャン

映画ソフトの持つスムーズな映像の動きと画質を再現するかどうかを「オン」「オフ」で選べます。

○色温度

画面全体の色味を調整します。

00(暖色)～10(寒色)の範囲で設定できます。

○ダイナミックガンマ

映像の内容に応じて、暗い部分から明るい部分にかけての階調が自動的に調整されます。00(メリハリ弱)～10(メリハリ強)の範囲で設定されます。

○ガンマ調整

映像の暗い部分と明るい部分の階調のバランスを調整します。

-5(暗い)～+5(明るい)の範囲で調整できます。

○2Dアバチャー

映像の横線の輪郭を強調したり弱めたりします。

「オート」「強」「中」「弱」「オフ」から選びます。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

音声設定メニュー


メニュー画面の「音声設定」を選んで **決定** を押します。



現在選択されている入力モード(テレビ、ビデオ、HDMI、PC)の音声を、お好みの音質に調整できます。

音声調整

お好みに合わせて音質調整をすることができます。



高音

設定値が小さいほど高音を弱め、設定値が大きいほど高音を強調します。

低音

設定値が小さいほど低音を弱め、設定値が大きいほど低音を強調します。

サラウンド

ステレオ音声を自然な広がり感を持ったサラウンドで再生する機能です。「オン」「オフ」で切り替えます。

高音強調

ドラマのセリフや楽器の輪郭を明りょうにして聞きやすくします。「オン」「オフ」で切り換えます。

低音強調

低音の効果を強くすることができます。「強」「弱」「オフ」で切り替えます。

初期設定に戻す

調整した内容をすべて出荷時の状態に戻します。

ご注意

ヘッドホンをご利用の場合は、音声調整の設定値は反映されません。

バランス

左右の音声出力のバランスを調整します。設定値が小さいほど左側を、設定値が大きいほど右側を強調します。



光デジタル音声出力

光デジタル音声出力端子から出力する音声信号を設定します。詳しくは39ページをご覧ください。

便利な機能を使う

映像を一時静止させる

1 を押す

解除するときは  もう一度押します。
一時静止中でも音声は流れ続けます。

字幕を見る

字幕切換で「日本語字幕」に設定すると、字幕放送になったときに字幕が表示されます。お買い上げ時は「字幕オフ(字幕を表示しない)」に設定されています。

字幕放送番組は、22ページ番組説明に  のアイコンが表示されます。(一部、表示と実際の放送が一致しない場合があります。)

1 を押す

2 ▲▼で「その他の設定」を選び、を押す

3 ▲▼で「信号切換」を選び、を押す

4 ▲▼で「字幕切換」を選び、を押す

5 「字幕オフ」または「日本語字幕」を ▲▼で選び、を押す

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

設定メニュー

メニュー画面の「設定」を選んで(決定)を押します。



設定メニューではお知らせ、機能設定、CEO設定、初期設定を行います。

お知らせ

- お知らせを見るには、「放送局からのお知らせ」と「本機に関するお知らせ」があります。
- 未読のお知らせがあると、チャンネル切替時や(画面表示)を押したときに画面に「お知らせアイコン」が表示されます。



1 (決定)を押す

2 ▲▼で「設定」を選び、(決定)を押す

3 ▲▼で「お知らせ」を選び、(決定)を押す



4 ▲▼でお知らせの種類を選び、(決定)を押す

- 放送局からのお知らせ … デジタル放送局からのお知らせです。
- 本機に関するお知らせ … 予約等について本機が発行したお知らせです。
- ボード ……………… 110度CSデジタル放送の視聴者に向けたお知らせです。

5 ▲▼で読みたいお知らせを選び、(決定)を押す

「本機に関するお知らせ」を削除する場合

○削除できるのは「本機に関するお知らせ」のみです。

- ① 「本機に関するお知らせ」の画面で(決定)を押す
- ② ◀▶で「はい」を選び、(決定)を押す

※ 「本機に関するお知らせ」がすべて削除されます。

ご注意

- 「放送局からのお知らせ」は、地上デジタルが7通まで記憶され、BSデジタルと110度CSデジタルは、合わせて24通まで記憶されます。(放送局の運用によっては、それよりも少ない場合もあります)記憶できる数を超えて受信した場合は、古いものから順に削除されます。
- 「本機に関するお知らせ」は既読の古いものか順に削除される場合があります。
- 「ボード」は110度CSデジタル放送のそれぞれに対し、今送信されているものが50通まで表示されます。

設定メニュー（つづき）


機能設定

機能設定では省エネ設定、視聴制限設定、外部入力設定、画面調整を行います。



省エネ設定

省エネ設定では消費電力、番組情報取得設定。無操作自動電源オフ、オンエアー無信号オフ、外部入力無信号オフ、クイックスタートの設定を行います。



○消費電力

バックライトの明るさを調整し消費電力を調整できます。

○番組情報取得設定

電源待機時に地上デジタル放送の番組情報を自動的に取得するかしないかを選択します。

○無操作自動電源オフ

テレビの無操作状態が約3時間続くと、電源が切れ待機状態にするかしないかを選択します。

○オンエアー無信号オフ

放送受信時に、無信号状態が約15分間続くと、電源が切れ待機状態にするかしないかを選択します。

○外部入力無信号オフ

外部入力選択時に、無信号状態が15分間続くと、電源が切れ待機状態にするかしないかを選択します。

○クイックスタート

「待機」状態のときに、リモコンの電源ボタンを押すと「クイックスタート」をするかしないかを選択します。

視聴制限設定

デジタル放送では番組ごとに視聴年齢が設定されている場合があります。視聴年齢制限のある番組を見るには、暗証番号を設定した状態で、以下の設定をする必要があります。

1 以下の操作で「視聴制限設定」画面にする

メニューを押します

- ▲▼で「設定」を選び、決定を押します。
- ▲▼で「機能設定」を選び、決定を押します。
- ▲▼で「視聴制限設定」を選び、決定を押します。


2 ▲▼で「視聴年齢制限設定」を選び、決定を押す

暗証番号の入力画面になります。

3 ①～⑩/0で暗証番号を入力する

4 ◀▶で年齢を設定し、決定を押す


設定できる年齢は、4歳から20歳までです。



○暗証番号を設定・変更する

視聴年齢制限のある番組を見るには、暗証番号の設定が必要です。

1 「視聴制限設定」画面で「暗証番号設定」を選び、決定を押す



暗証番号を入力する画面が表示されます。暗証番号を変更する場合は、すでに設定されている暗証番号を入力してください。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

設定メニュー(つづき)

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

2 [1]～[10%]で新しく設定する暗証番号を入力する

3 確認のため、新しく設定する暗証番号をもう一度入力する

4 (決定)を押す
暗証番号が設定されます。

○ 暗証番号を削除する

視聴年齢制限のある番組を見るには、暗証番号の設定が必要です。

1 「視聴制限設定」画面で「暗証番号削除」を選び、(決定)を押す

2 [1]～[10%]で現在設定されている暗証番号を入力する
確認画面が表示されます。

3 ◀▶で「はい」を選び、(決定)を押す
暗証番号が設定されます。

外部入力設定

外部機器を接続する場合に設定します。詳しくは41ページをご覧ください。

画面調整

画面の位置や幅を調整します。詳しくは29ページをご覧ください。

CEC設定

HDMI連動設定を行います。詳しくは40ページをご覧ください。

初期設定

初期設定メニューに表示される項目は、地上デジタル、PC入力など、選択している入力モードによって異なります。入力モードを選んでからメニューを押して(決定)を表示し、▶▶で「初期設定」を選択してください。



はじめての設定

引越しなどでお住まいの地域が変わったときには、「はじめての設定」を行ってください。操作手順は19ページをご覧ください。

アンテナ設定

アンテナの方向調整と設定を行います。詳しくは、45ページをご覧ください。

チャンネル設定

○ 地上デジタル自動設定

引越した場合などこのメニューからチャンネルを設定してください。状況に応じて「初期スキャン」か「再スキャン」を選びます。

「初期スキャン」を選ぶと現在の内容がクリアされ、自動的に受信できるチャンネルをスキャンし、設定します。購入後初めて設定する場合、違う地域に引越した場合は、こちらを選びます。

「再スキャン」を選びスキャン後にすべてを設定し直すか、現在の設定に追加するかを選択できます。

初期設定メニュー(つづき)

○ 手動設定(地上デジタル/BS/110度CS)

リモコンの数字キーに、どのチャンネルを当てるかを設定します。

位次	チャンネル	放送局
1	テレビ	NHK総合・東京
2	テレビ	NHKEテレ東京
3	テレビ	t v k
4	地デジ 031	t v k 1
5	地デジ 021	NHKEテレ1東京
6	テレビ	TBS

1 ▲▼で変更したい数字キーを選んで(決定)を押す

2 ◀▶でチャンネルを変更し、▼を押す

3 必要に応じて、◀▶で放送局を変更し、▼を押す

4 ◀▶で「設定完了」を選び、(決定)を押す

○ 地デジ難視対策衛星放送

地デジ難視対策衛星放送とは、地上デジタル放送が送り返り届かない地区にお住まいの方に、テレビ放送を視聴いただけるように、暫定的に衛星放送を利用して地上デジタル放送の番組をご覧いただくものです。

お買い上げ時、本機は地デジ難視対策衛星放送の視聴や番組表示ができないようになっています。

設定について詳しくは23ページをご覧ください。

○ チャンネルスキップ設定

[はい]で選局するときに、不要なチャンネルを飛び越すことができます。

1 設定したい放送の種類を▲▼で選び、(決定)を押す

2 スキップ設定を変更したいチャンネルを▲▼で選び、(決定)を押す

位次	チャンネル	放送局	スキップ
1	1	NHK総合・東京	受信
2	2	NHKEテレ東京	スキップ
3	3	t v k	受信
4	4	日本テレビ	受信
5	5	テレビ朝日	受信
6	6	TBS	受信

(決定)を押すたびに「受信」⇔「スキップ」と交互に切り換わります

デジタル放送の放送メディア(テレビ/ラジオ/データ)を変えるときは、(決定)を押します。

○ 初期設定に戻す

すべてのチャンネル設定と、「登録されている郵便番号」、「音量」をお買い上げ時の状態に戻します。

1 ▲▼で「初期設定に戻す」を選び、(決定)を押す

2 ◀▶で「はい」を選び、(決定)を押す

ご利用前に

テレビを見る準備

基本の操作


外部機器との接続

調整と設定

その他

設定メニュー(つづき)


データ放送設定



データ放送を見る際の設定を行います。

○郵便番号入力

お住まいの郵便番号を入力しておくことにより、データ放送において、地域の情報を得ることができます。



数字ボタン(①～⑩)で郵便番号を入力します。「0」は⑩ボタンで入力されます。

○文字スーパー表示設定

見ている番組とは連動せずに速報ニュースなどを表示するものです。「表示する」「表示しない」が設定できます。

○ルート証明書番号


地上デジタル放送の双方用サービスで、本機と接続するサーバーの認証をする際に使用されます。

通信設定

LAN端子の接続をした場合に設定します。設定について詳しくは、43ページをご覧ください。

B-CASカードの確認

本機にセットされているminiB-CASカードの状態を表示します。(決定)を押すとminiB-CASカードの番号を表示します。




ソフトウェアのダウンロード

ソフトウェア自動更新の設定や、ソフトウェアバージョンを確認できます。



○放送からのダウンロード

本機のソフトウェアを自動的にダウンロードして更新するか設定します。



「ダウンロードする」に設定しておくと、新しいソフトウェアが配信された際、自動的にダウンロードと更新が行われます。「ダウンロードしない」に設定している場合は、「お知らせ(メール)」の「本機に関するお知らせ」に、ソフトウェア配信の日時を知らせるメールが届きます。配信日時に「する」に設定してください。

ご注意

- 主電源がオフになっていると、ソフトウェアのダウンロードを行えません。コンセントを抜かないようご注意ください。
- アンテナ受信レベルが低い場合、ソフトウェアのダウンロードは行えません。NHKのアンテナレベルが50以上になるよう、アンテナを調整してください。

○ソフトウェアバージョン

現在のソフトウェアのバージョンを表示します。



設定の初期化

○すべての初期化

すべての設定をお買い上げ時の状態に戻し、個人情報进行を消去します。

○HDDの初期化

本機に接続しているUSBハードディスクを初期化します。

タイマー機能メニュー

オンタイマーを使う

設定した時刻に本機の電源が「入」になります。オンタイマーは、デジタル放送を受信していない場合や時刻情報を取得していない場合には使用できません。

1 を押す

2 ▲▼で「タイマー機能」を選び、 を押す

3 ▲▼で「オンタイマー」を選び、 を押す



4 「オンタイマー」で設定する項目を ▲▼ で選び、 を押す

オンタイマー機能

オンタイマーを使用する、使用しないを設定します。

- ▲▼で「オンタイマー機能」を選び、 を押す
- ▲▼で「入」を選び、 を押す

○オンタイマーを設定したあとにオンタイマーを解除したい場合は、上記の手順で「切」を選びます。

日時

オンタイマーで本機の電源を「入」にする日時を設定します。

- ▲▼で「日時」を選び、 を押す
- ◀▶で設定する項目を選び、▲▼で日時を選ぶ

○曜日は「毎日」、「毎週(日)～「毎週(土)」、「月～木」、「月～金」「月～土」の中から選びます。



- 設定が終わったら、 を押す

チャンネル

オンタイマーで電源が「入」になったときに、画面に映すチャンネルを設定します。

- ▲▼で「チャンネル」を選び、 を押す
- ▲▼でチャンネルを選び、 を押す
- 設定が終わったら、 を押す

○放送の種類：地デジ/BS/CS

○チャンネル：指定された放送の種類やメディアに該当するチャンネル

音量

オンタイマーで電源が「入」になったときの音量を設定します。

- ▲▼で「音量」を選び、 を押す
- ▲▼で好みの音量を選び、 を押す

5 「オンタイマー」を「入」にした後は、リモコンの電源ボタンで電源を切る

本体の電源ボタンで電源を切らないでください。

※ オンタイマー作動後、無操作状態で約1時間続くと自動的にOFFになります。画面には「まもなく電源が切れます」と表示されます。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

タイマー機能メニュー

オフタイマーを使う

オフタイマーを設定すると、設定時間後に電源が切れて、待機状態になります。

1  を押す

2 ▲▼で「タイマー機能」を選び、 を押す

3 ▲▼で「オフタイマー」を選び、 を押す



4 ▲▼で設定時間を選び、 を押す

電源が切れる1分前になると、画面にメッセージが表示されます。

オフタイマーが設定されているときに  を押すと、メニューの「タイマー機能」に電源が切れるまでの残り時間が表示されます。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

地域別チャンネル表

リモコンの数字ボタンに割り当てられる地上デジタル放送局は下記のとおりです。

(まだ放送を開始していない放送局もあります)

引越しや新しく放送局が開局されるなどでチャンネルを割り当て直したいときは、地上デジタルモードで初期設定メニューを表示し、「チャンネル設定」の「地上デジタル自動設定」で「地域選択」と「初期スキャン」または「再スキャン」を行ってください。

都道府県	チャンネル ポジション	放送局
北海道 (帯広)	3	NHK総合・帯広
	2	NHK教育・帯広
	1	HBC帯広
	5	STV帯広
	6	HTB帯広
	8	UHB帯広
	7	TVH帯広
北海道 (釧路)	3	NHK総合・釧路
	2	NHK教育・釧路
	1	HBC釧路
	5	STV釧路
	6	HTB釧路
	8	UHB釧路
	7	TVH釧路
北海道 (北見)	3	NHK総合・北見
	2	NHK教育・北見
	1	HBC北見
	5	STV北見
	6	HTB北見
北海道 (旭川)	3	NHK総合・旭川
	2	NHK教育・旭川
	1	HBC旭川
	5	STV旭川
	6	HTB旭川
	8	UHB旭川
	7	TVH旭川
北海道 (札幌)	3	NHK総合・札幌
	2	NHK教育・札幌
	1	HBC札幌
	5	STV札幌
	6	HTB札幌
	8	UHB札幌
	7	TVH札幌
北海道 (函館)	3	NHK総合・函館
	2	NHK教育・函館
	1	HBC函館
	5	STV函館
	6	HTB函館
	8	UHB函館
	7	TVH函館
北海道 (室蘭)	3	NHK総合・室蘭
	2	NHK教育・室蘭
	1	HBC室蘭
	5	STV室蘭
	6	HTB室蘭
青森	3	NHK総合・青森
	2	NHK教育・青森
	1	RAB青森放送
	6	ATV青森テレビ
	5	青森朝日放送
岩手	1	NHK総合・盛岡
	2	NHK教育・盛岡
	6	IBCテレビ
	4	テレビ岩手
	5	めんこいテレビ 岩手朝日テレビ

都道府県	チャンネル ポジション	放送局	
宮城	3	NHK総合・仙台	
	2	NHK教育・仙台	
	1	TBCテレビ	
	8	仙台放送	
	4	ミヤギテレビ	
	5	KHB東日本放送	
	1	NHK総合・秋田	
	2	NHK教育・秋田	
秋田	4	ABS秋田放送	
	8	AKT秋田テレビ	
	5	AAB秋田朝日放送	
	1	NHK総合・山形	
	2	NHK教育・山形	
山形	4	YBC山形放送	
	5	YTS山形テレビ	
	6	テレビユー山形	
	8	さくらんぼテレビ	
	1	NHK総合・福島	
福島	2	NHK教育・福島	
	8	福島テレビ	
	4	福島中央テレビ	
	5	KFB福島放送	
	6	テレビユー福島	
	1	NHK総合・水戸	
茨城	2	NHK教育・東京	
	4	日本テレビ	
	6	TBS	
	8	Fジテレビジョン	
	5	テレビ朝日	
	7	テレビ東京	
栃木	12	放送大学	
	1	NHK総合・東京	
	2	NHK教育・東京	
	4	日本テレビ	
	6	TBS	
	8	Fジテレビジョン	
	5	テレビ朝日	
	7	テレビ東京	
	3	とちぎテレビ	
	12	放送大学	
	群馬	1	NHK総合・東京
		2	NHK教育・東京
4		日本テレビ	
6		TBS	
8		Fジテレビジョン	
5		テレビ朝日	
7		テレビ東京	
3		群馬テレビ	
埼玉	12	放送大学	
	1	NHK総合・東京	
	2	NHK教育・東京	
	4	日本テレビ	
	6	TBS	
	8	Fジテレビジョン	
	5	テレビ朝日	
	7	テレビ東京	

都道府県	チャンネル ポジション	放送局	
千葉	1	NHK総合・東京	
	2	NHK教育・東京	
	4	日本テレビ	
	6	TBS	
	8	Fジテレビジョン	
	5	テレビ朝日	
	7	テレビ東京	
	3	チバテレビ	
	12	放送大学	
	東京	1	NHK総合・東京
		2	NHK教育・東京
		4	日本テレビ
6		TBS	
8		Fジテレビジョン	
5		テレビ朝日	
7		テレビ東京	
9		TOKYO MX	
12		放送大学	
神奈川		1	NHK総合・東京
		2	NHK教育・東京
		4	日本テレビ
	6	TBS	
	8	Fジテレビジョン	
	5	テレビ朝日	
	7	テレビ東京	
	3	tvk	
新潟	12	放送大学	
	1	NHK総合・新潟	
	2	NHK教育・新潟	
	6	BSN	
	8	NST	
	4	TeNYテレビ新潟	
	5	新潟テレビ21	
	3	NHK総合・富山	
富山	2	NHK教育・富山	
	1	KNB北日本放送	
	8	BBT富山テレビ	
	6	チューリップテレビ	
	1	NHK総合・金沢	
	2	NHK教育・金沢	
石川	4	テレビ金沢	
	5	北陸朝日放送	
	6	MRO	
	8	石川テレビ	
	福井	1	NHK総合・福井
		2	NHK教育・福井
7		FBCテレビ	
8		福井テレビ	
山梨	1	NHK総合・甲府	
	2	NHK教育・甲府	
	4	YBS山梨放送	
	6	UTY	
長野	1	NHK総合・長野	
	2	NHK教育・長野	
	4	テレビ信州	
	5	abn長野朝日放送	
	6	SBC信越放送	
8	NBS長野放送		

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

地域別チャンネル表

都道府県	チャンネル ポジション	放送局
静岡県	1	NHK総合・静岡
	2	NHK教育・静岡
	6	SBS
	8	テレビ静岡
	4	静岡第一テレビ
岐阜県	5	静岡朝日テレビ
	3	NHK総合・岐阜
	2	NHK教育・名古屋
	1	東海テレビ
	5	CBC
愛知県	6	メーテレ
	4	中京テレビ
	8	岐阜テレビ
	3	NHK総合・名古屋
	2	NHK教育・名古屋
三重県	1	東海テレビ
	5	CBC
	6	メーテレ
	4	中京テレビ
	10	テレビ愛知
滋賀県	3	NHK総合・津
	2	NHK教育・名古屋
	1	東海テレビ
	5	CBC
	6	メーテレ
京都府	4	中京テレビ
	7	三重テレビ
	1	NHK総合・大津
	2	NHK教育・大阪
	4	MBS毎日放送
大阪府	6	ABCテレビ
	8	関西テレビ
	10	読売テレビ
	3	BBCひょう湖放送
	1	NHK総合・京都
兵庫県	2	NHK教育・大阪
	4	MBS毎日放送
	6	ABCテレビ
	8	関西テレビ
	10	読売テレビ
奈良県	7	テレビ大阪
	1	NHK総合・神戸
	2	NHK教育・大阪
	4	MBS毎日放送
	6	ABCテレビ
和歌山県	8	関西テレビ
	10	読売テレビ
	3	サンテレビ
	1	NHK総合・奈良
	2	NHK教育・大阪

都道府県	チャンネル ポジション	放送局
和歌山県	1	NHK総合・和歌山
	2	NHK教育・大阪
	4	MBS毎日放送
	6	ABCテレビ
	8	関西テレビ
鳥取県	10	読売テレビ
	5	テレビ和歌山
	3	NHK総合・鳥取
	2	NHK教育・鳥取
	8	山陰中央テレビ
島根県	6	BSSテレビ
	1	日本海テレビ
	3	NHK総合・松江
	2	NHK教育・松江
	8	山陰中央テレビ
岡山県	6	BSSテレビ
	1	日本海テレビ
	1	NHK総合・岡山
	2	NHK教育・岡山
	4	FNC西日本テレビ
広島県	5	KBS瀬戸内海放送
	6	RSKテレビ
	7	テレビせとうち
	8	OHKテレビ
	1	NHK総合・広島
山口県	2	NHK教育・広島
	3	RCCテレビ
	4	広島テレビ
	5	広島ホームテレビ
	8	TSS
徳島県	1	NHK総合・山口
	2	NHK教育・山口
	4	KRY山口放送
	3	tysテレビ山口
	5	yab山口朝日
香川県	3	NHK総合・徳島
	2	NHK教育・徳島
	1	四国放送
	1	NHK総合・高松
	2	NHK教育・高松
愛媛県	4	FNC西日本テレビ
	5	KSB瀬戸内海放送
	6	RSKテレビ
	7	テレビせとうち
	8	OHKテレビ
高知県	1	NHK総合・松山
	2	NHK教育・松山
	4	南海放送
	5	愛媛朝日
	6	あいテレビ
福岡県	8	テレビ愛媛
	1	NHK総合・高知
	2	NHK教育・高知
	4	高知放送
	6	テレビ高知
佐賀県	8	さんさんテレビ
	3	NHK総合・福岡
	3	NHK総合・北九州
	2	NHK教育・福岡
	2	NHK教育・北九州
長崎県	1	KBC九州朝日放送
	4	FKB毎日放送
	5	FBS福岡放送
	7	TVQ九州放送
	8	TNCテレビ西日本

都道府県	チャンネル ポジション	放送局
佐賀県	1	NHK総合・佐賀
	2	NHK教育・佐賀
	3	STSサガテレビ
	1	NHK総合・長崎
	2	NHK教育・長崎
熊本県	3	NBC長崎放送
	8	KTNテレビ長崎
	5	NCC長崎文化放送
	4	NIB長崎国際テレビ
	1	NHK総合・熊本
大分県	2	NHK教育・熊本
	3	FKK熊本放送
	8	TKUテレビ熊本
	4	KKTくまもと県民
	5	KAB熊本朝日放送
宮崎県	1	NHK総合・大分
	2	NHK教育・大分
	3	OBS大分放送
	4	TOSテレビ大分
	5	OAB大分朝日放送
鹿児島県	2	NHK総合・宮崎
	1	NHK教育・宮崎
	6	MRT宮崎放送
	3	UMKテレビ鹿嶋
	3	NHK総合・鹿児島
沖縄県	2	NHK教育・鹿児島
	1	MBC南日本放送
	8	KTS鹿児島テレビ
	5	KKB鹿児島放送
	4	KYT鹿児島読売TV
沖縄県	1	NHK総合・那覇
	2	NHK教育・那覇
	3	FBCテレビ
	5	QAB琉球朝日放送
	8	沖縄テレビ (OTV)

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定


その他

故障かな?と思ったら

つぎのような場合は故障ではないことがあります。修理をご依頼になる前にもう一度ご確認ください。

まずはご確認ください

電源が入らなかったり、放送が映らなかったりした場合は、まず以下を確認してください。



こんな場合は故障ではありません

- 画面上に赤や青、緑の点(輝点)が消えなかったり、黒い点がある
液晶画面は非常に精密な技術で作られており、99.99%以上の有効画素がありますが、ごくわずかの画素欠けや常時点灯する画素がある場合があります。
- キャビネットから「ピシッ」というきしみ音がする
部屋の温度変化でキャビネットが伸縮するときに発生する音です。画面や音声などに異常がなければ心配ありません。
- 本機の内部から「カチッ」という音がする
本機は、電源が「待機」のときに番組情報取得などの動作をします。このときに、内部から「カチッ」という音が聞こえることがあります。

全般

症状	原因や対処の仕方
電源が入らない	○電源プラグがコンセントから抜けていませんか? → 電源コードの接続を確認してください。
リモコンが操作できない	○リモコンを受光部に向けていますか? ○お部屋の蛍光灯の強い光がリモコン受光部に当たっていませんか? → リモコン受光部に強い光を当てないでください。 ○乾電池が消耗していませんか? → 新しい乾電池に交換してみてください。 ○乾電池の極性(+-)が逆になっていませんか? → 正しく入れ直してください。 ○テレビ本体の電源ボタンでOFFにしていませんか? → テレビ本体の電源ボタンでOFFにした場合、リモコンでの操作を行うことが出来ません。(17ページ参照)
突然電源が切れた	○オフタイマーを設定していませんか? → オフタイマーの設定を確認してください。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

故障かな?と思ったら(つづき)

映像

症状	原因や対処の仕方
映像が出ない AV映像が出ない	<p>○アンテナは正しくつながっていますか? → アンテナの接続を確認してください。</p> <p>○明るさは正しく調整されていますか? → 明るさの調整をしておしてください。</p> <p>○外部機器と正しく接続されていますか? → 外部機器の接続と電源を確認してください。</p>
映像も音声も出ない	<p>○電源プラグがコンセントから抜けていませんか? → 電源コードの接続を確認してください。</p> <p>○電源スイッチは入っていますか? → 電源スイッチを入れてください。</p> <p>○テレビモード以外の入力モードになっていませんか? → テレビモードに設定してください。</p>
映像も音声もノイズしか出ない	○アンテナケーブルが正しく接続されていますか?
映像や音声が出なくなる、または時々出なくなる 映像が静止する、または時々静止する	<p>○アンテナの向きが、風や振動によって変わっていませんか? → アンテナを調整してください。</p> <p>○アンテナ線の劣化が考えられます。 ○着雪(アンテナ)、雨、雷雨などによる電波の減衰や、強風時のアンテナの揺れなどが考えられます。雷雨や豪雨の中では、受信電波が弱くなり、また雪がアンテナに積もると受信状態が悪くなるため、一時的に映像や音声が止まったり、ひどいときにはまったく受信できなくなったりすることがあります。天候の回復を待ってください。</p>
映りが悪い	<p>○アンテナケーブルが正しく接続されていますか?</p> <p>○電波状態が悪いことが考えられます。</p>
色合いが悪い、色が薄い	○色の濃さ、色合いは正しく調整されていますか?
画面が暗い	<p>○明るさは正しく調整されていますか? → 明るさの調整をしておしてください。</p>
接続した機器の映像がでない	<p>○外部機器は正しくつながっていますか? → 外部機器の接続と電源を確認してください。</p> <p>○入力切替は合っていますか? → リモコンまたは本体の入力切替ボタンで、入力を切り換えてください。</p>

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

故障かな?と思ったら(つづき)

音声

症状	原因や対処の仕方
音が出ない	<ul style="list-style-type: none">○音量が最小になっていませんか?○「消音」状態になっていませんか?○イヤホンが接続されていませんか?

デジタル放送

症状	原因や対処の仕方
地上デジタル放送が受信できない	<ul style="list-style-type: none">○B-CASカードは正しく挿入されていますか?○地上デジタル放送用アンテナは正しく接続されていますか?
引越したら、地上デジタル放送が受信できなくなった	<ul style="list-style-type: none">○「初期設定」の「地上デジタル自動設定」をやり直してください。
番組表が表示されない 表示されるチャンネルが少ない	<ul style="list-style-type: none">○お買い上げ時、または長時間電源を切った状態のあとは、番組表の表示に時間がかかる場合があります。しばらく視聴すると表示されます。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

故障かな?と思ったら(つづき)

録画

症状	原因や対処の仕方
USBハードディスクが認識されない	<p>○本機に対応したUSBハードディスクですか? →本機で接続確認済みの機器以外では、使用できないことがあります。対応している機器については、75ページをご覧ください。</p> <p>○USBハードディスクが正しく接続されていますか? →USBハードディスクを正しく接続してください(22ページ)。 USBハブを経由した場合は正しく動作しないことがあります。</p> <p>○USBハードディスクが本機に登録されていますか? →USBハードディスクを本機に登録してください(22ページ)。</p>
録画できない	<p>○USBハードディスクの電源が入っていますか? →電源オンが必要なUSBハードディスクの場合は、電源をオンにしてください。</p> <p>○USBハードディスクの空き容量が不足していませんか? →不要な番組を削除するか、「自動削除設定」を「削除する」にしてください(52ページ)。</p> <p>○録画できない映像ではありませんか? →コピー禁止の番組や、独立データ放送、ラジオ放送番組、外部入力からの映像・音声は録画できません。</p> <p>○放送開始時刻が変更されていませんか? →録画予約した番組の放送開始時刻が繰り上げられた場合は録画できません。放送開始時刻が変更になり録画できなかった場合は、「設定」メニューの「お知らせ」で確認できます。</p>
録画した番組が消えた	<p>○「自動削除設定」が「削除する」になっていませんか? →「自動削除設定」を「削除しない」に設定してください。または、消したくない番組を選び「保護設定」を「保護する」に設定してください。</p>
録画した番組が再生できない	<p>○本機で録画した番組は、本機以外ではご覧になれません。</p>

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

エラーメッセージ一覧

代表的なエラーメッセージ表示について説明します。

デジタル放送

症状	原因や対処の仕方
このチャンネルはご覧になれません	放送されていないチャンネルを選局しています。別のチャンネルを選局してください。
信号が受信できません	雨などの影響により、一時的に受信レベルが低下しています。しばらくお待ちください。アンテナの接続が正しく行われているかも確認してください。
電波の受信状態が良くありません。 クイックメニューから降雨対応放送に切り替えられます。	気象条件などによって信号レベルが下がり、降雨対応放送切替が可能な状態になったため。
現在放送されていません	放送を休止しているチャンネルを選局しています。別のチャンネルを選局してください。
チャンネルが設定されていません	チャンネルが割り当たっていない数字キーを押したときに表示されません。
このB-CASカードは使用できません	B-CASカードが挿入されていない、または使用できないカードが挿入されています。付属のB-CASカードを正しく入れてください。
B-CASカードが正しく挿入されていません	B-CASカードが挿入されていないときに表示されます。
このB-CASカードは交換が必要です B-CASカードが故障しています	B-CASカードが故障しています。
このICカードはご使用になれません	無効なICカードが挿入されています。B-CASカードを挿入してください。
放送チャンネルではないためご覧になれません	放送チャンネルを選択しなおしてください。
未読メールがあります	ソフトウェアのアップデートなどの情報メールが到着しています。メールを確認してください。
ソフトウェアのダウンロード中です	ソフトウェアをダウンロードしています。そのままお待ちください。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

エラーメッセージ一覧(つづき)

録画

症状	原因や対処の仕方
USBハードディスクにエラーが発生したため、録画予約を中止しました。	USBハードディスクに障害が発生して、録画を継続できなかった。
USBハードディスクの残量がなかったため、録画予約を中止しました。	USBハードディスクの残量が無くなり、録画を継続できなかった。
USBハードディスクに録画できる番組数がいっぱいなため、録画予約を実行できませんでした。	USBハードディスクに録画している番組数が300件であったため、録画予約を実行できなかった。
録画予約チャンネルに選局できなかったため、録画予約を実行できませんでした。	録画予約していたチャンネルが放送局の変更により消失したため、録画予約を実行できなかった。
コピー制限により録画できませんでした。	放送された番組がコピー不可(Copy Never)のため、録画できなかった。
番組が放送時間不足のため、予約を実行できませんでした。	録画の開始時間から終了時間までが30秒未満だったため、録画予約を実行できなかった。
番組に映像が存在しないため、予約を実行できませんでした。	番組に映像コンポーネントが存在しなかったため、録画できなかった。
下記の番組は、契約判定により録画できませんでした。	予約対象番組が非契約だったため、録画できなかった。
下記の番組は、B-CASカードのアクセスエラーにより録画できませんでした。	スクランブル放送でminiB-CASカードが抜去されていたため、録画できなかった。
予約設定した番組が放送されませんでした。または、放送時間が繰り上げられました。	予約した番組が放送されなかった、もしくは放送時間が繰り上げられて、録画予約を実行できなかった。
下記の番組は、受信状態の悪化により録画できませんでした。	受信状態が悪化して放送を受信できなかったため、録画できなかった。
録画予約実行時に停電や電源コードが抜かれたため、予約を取り消しました。	録画予約の開始時間から終了時間までの一部、もしくはすべてで、本体電源がオフとなっていたため、録画できなかった。
他の録画予約が実行中のため、予約を取り消しました。	録画予約が重なったため、録画予約を実行できなかった。
12時間以上の録画となったため、録画予約を中止しました。	録画の開始時間から12時間以上となったため、録画を停止した。
下記の番組は、機器のエラーにより録画できませんでした。	テレビになにかしらの異常が発生し、録画予約を実行できなかった。
ユーザー操作により、録画予約を中止しました。	ユーザー操作によって録画予約を中止した。
USBハードディスクが起動完了、もしくはスピンドル完了していないため、録画予約を中止しました。	録画開始時にUSBハードディスクが起動しない、もしくはスピンドルしなかったため、録画予約を実行できなかった。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続


調整と設定

その他

壁掛けでご使用になるとき

本機は市販の壁掛け金具を使用して、壁に取り付けることができます。

- テレビを取り付ける壁の強度には十分ご注意ください。
- 壁掛け金具の取り付けは、必ず専門の業者にご依頼ください。
- 専門業者以外の方が取り付けたり、壁への取り付けが不適切だったりすると、テレビが落下して、打撲や大けがの原因となることがあります。



お知らせ

ネジ穴寸法は200mm×200mmです。
VESA規格に準じた金具をご購入ください。


ご注意

- 壁掛け金具の本体側固定用には、付属のM6×14mmのネジをご使用ください。
- 長いネジをご使用になると内部の部品へダメージを与え製品を損傷致します。

スタンドのはずしかた

本機を壁掛けでご使用になるときは、スタンドをはずしてください。

- 1 テーブルなどの台の上に毛布などのやわらかい布を敷き、その上に液晶画面を下向きにして本機を置く
- 2 スタンド固定用ネジ(4箇所)を取りはずし、スタンドを本体の下方向に引いてはずす



ご注意

- 液晶パネルを傷つけないよう取り扱いにご注意ください。
- はずしたネジは、再度スタンドを取り付ける場合に必要です。スタンドと共に保管してください。

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

主な仕様

テレビ

型名	J40SK01	
種類	液晶デジタルフルハイビジョンテレビ	
液晶パネル	画面サイズ	40V (39.5inches)
	バックライト	LED
	駆動方式	TFTアクティブマトリクス
	画素数	1920(H)×1080(V)
	応答速度	8.5ms Gray to gray (BW)
	視野角(最小値)	左右約 176°(MIN)/上下約 176°(MIN)
	輝度(最大値)	250cd /㎡
	コントラスト比(標準値)	5000:1
地上波デジタル	地上デジタル:UHF(13~62ch) CATV/バスルー(VHF,UHF)対応共有	
BSデジタル	BSデジタル:BS000~BS999	
110°CSデジタル	110度CSデジタル:CS000~CS999	
音声出力(スピーカー)	8W+8W	
入力・出力端子	ビデオ入力×1	映像:1V(p-p)、75Ω、負荷期 音声:500mV(rms)、22kΩ以上(インピーダンス)
	HDMI入力×3	HDMI Ver.1.3標準規格 CEC対応 対応入力解像度:480i,480p,720p,1080i,1080p
	USB×1	録画用外付けHDD専用
	光デジタル音声出力	×1
	ヘッドホン出力	ヘッドホン端子口径 3.5mm ステレオミニジャック 適合インピーダンス 16Ω~
HDD録画機能	裏番組録画対応(ダブルチューナー)、番組表から録画予約可能(最大録画予約件数64)、最大録画番組数300(最大2TBまでの外付けHDD対応)、日時指定予約機能、自動削除/保護機能、放送時間運動機能、レジューム再生、追っかけ再生、頭出し再生、ワンタッチスキップ機能、HDD省エネ設定機能	
データ放送	双方向データ放送(BML)対応	
番組表	電子番組表(EPG)対応:6チャンネル5時間分表示、8日分受信、視聴予約可能 双方向データ放送(BML)対応	
使用環境/保管環境	温度:0℃~35℃/ -20℃~45℃ 湿度:20%~80%RH/ 10%~90%RH(結露のないこと) 高度:0~2,000m / 0~3,790m	
サイズ(W.H.D)	906.7mm×228.4mm×556.8mm	
重量	6.7kg(NET),9kg(総重量)	
消費電力(待機電力)	90W(0.5w)	
年間消費電力	72kWh/年	
付属品	リモコン(MS002)、リモコン用単4乾電池×2個、B-CASカード×1枚、B-CASカード紛失防止ホルダー×1個、B-CASカード紛失防止ホルダー固定用ネジ×1個、スタンドベース×2個、スタンドベース固定ネジ×4個、取扱説明書×1部、保証書×1部	

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

主な仕様

リモコン(MS002)

電源	DC 3V(単4形乾電池×2)
質量	92.5 g(乾電池を含まない)
リモコン操作距離	約7m(ただし直進)

* 製品仕様は予告なく変更されることがあります。

年間消費電力とは、省エネルギー法に基づいて型サイズや受信機の種類別の算定式により、一般家庭での平均視聴時間を基準に算出した、1年間に使用する電力量です。

このテレビをご使用できるのは、日本国内のみで外国では使用できません。

外付けHDD対応機器一覧

本機にて接続可能な外付けUSBハードディスクは以下のとおりです。各ホームページの情報もご確認ください。

アイ・オー・データ製

○HDCL-UTB シリーズ(据え置きタイプ)

<http://www.iodata.jp/product/hdd/hdd/hdcl-utb/>

動作確認済み:HDCL-UT2.0KC

○AVHD-AUT シリーズ(据え置きタイプ)

<http://www.iodata.jp/product/hdd/hdd/avhd-aut/>

動作確認済み:AVHD-AUT1.0

○HDPC-UTC シリーズ(ポータブルタイプ)

<http://www.iodata.jp/product/hdd/portable/hdpc-utc/>

動作確認済み:HDPC-UT500KC

○AVHD-PU シリーズ(据え置きタイプ)

<http://www.iodata.jp/product/hdd/portable/avhd-pu/>

動作確認済み:AVHD-P1.0U

○HDUS-UT シリーズ(ポータブルタイプ)

<http://www.iodata.jp/product/hdd/portable/hdus-ut/>

動作確認済み:HDUS-UT1.0K

バッファロー社製

○HD-LCU3-C シリーズ(据え置きタイプ)

<http://buffalo.jp/product/hdd/external/hd-lcu3c/>

動作確認済み:HD-LCU3-C

○HD-LLU3 シリーズ(据え置きタイプ)

<http://buffalo.jp/product/hdd/external/hd-llu3/>

動作確認済み:HD-LLU3

○HD-LCU3 シリーズ(据え置きタイプ)

<http://buffalo.jp/product/hdd/external/hd-lcu3/>

動作確認済み:HD-LCU3

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

保証とアフターサービス

基本的な取り扱い方法、故障と思われる場合のご確認

ホームページ上にも情報を掲載しておりますのでご覧ください。

www.maxzen.jp

故障と思われる場合のご相談について

この取扱説明書内にあります「故障かな?と思ったら」の内容や上記ホームページをチェックしても問題が解決できない場合、まず電源プラグを抜いてお買い上げの販売店もしくはマクスゼンテクニカルセンターまでご連絡ください。

マクスゼンテクニカルセンター TEL:047-401-2668

○お客様からご提供いただいた個人情報、修理やご相談への回答、カタログ発送などの情報提供に利用いたします。
○利用目的の範囲内で、当該製品に関連するグループ会社や協力会社にお客様の個人情報を提供する場合があります。

修理について

当社では原則的に出張修理を行っておりません。
センドバック修理となりますので予めご了承ください。

部品について

修理のために取り外した部品は、特段のお申し出がない限り当社で引き取らせて頂きます。また、修理の際、当社の品質基準に適合した再利用部品を使用することがあります。

保証書(別添)

保証書は必ず「お買い上げ日」「販売店名」等の記入をお確かめの上、販売店から受け取っていただき内容をよくお読みの上、たいせつに保管してください。

保証期間…お買い上げの日から1年間です。
(miniB-CASカードは、保証の対象から除きます)

修理を依頼されるときは

保証期間中は

修理に関しては保証書をご覧ください。保証書の規定に従って販売店もしくはマクスゼンテクニカルセンターが修理をさせていただきます。

保証期間が過ぎているとき

修理をすれば使用出来ると思われる場合には、ご希望によって有料で修理させていただきます。

修理料金について

修理料金は、技術料・部品代・製品の送料などで構成されています。当社では原則的に出張修理は行っておりません。

技術料	故障した製品を正常に修復するための料金です。
部品代	修理に使用した部品代金です。
送料	製品を修理会社まで運搬するための費用です。

ご連絡していただきたい内容

製品名	
製品型番	
お買い上げ日	年 月 日
故障の状況	できるだけ具体的に
接続している機器	
お名前	
ご住所	
電話番号	

廃棄時にご注意願います。 家電リサイクル法では、ご使用済の液晶テレビを廃棄する場合は、収集・運搬料金、再商品化等料金(リサイクル料金)をお支払いの上、対象品を販売店や市町村に適正に引き渡すことが求められています。



長年ご使用のテレビの点検をぜひ！ 熱、湿気、ホコリなどの影響や、使用の量合いによって部品が劣化し、故障したり、ときには安全性を損なって事故につながることもあります。

ご使用の際
このような症状は
ありませんか？

- 電源を入れても映像や音が出ない。
- 映像が時々、消えることがある。
- 変なにおいがしたり、煙が出たりする。
- 電源を切っても、映像や音が消えない。
- 内部に水や異物がはいった。

ご使用中

このような場合、故障や事故防止のため、すぐに電源プラグをコンセントから抜いて、必ずお買い上げの販売店に点検・修理をご相談ください。
ご自分での修理は危険ですので、絶対にしないでください。

ソフトウェアのライセンス情報

本製品に組み込まれたソフトウェアは、複数の独立したソフトウェアコンポーネントで構成され、個々のソフトウェアコンポーネントは、それぞれに第三者の著作権が存在します。

本製品は、第三者が規定したエンドユーザーライセンスアグリーメントあるいは著作権通知(以下、「EULA」といいます)に基づきフリーソフトウェアとして配布されるソフトウェアコンポーネントを使用しております。「EULA」の中には、実行形式のソフトウェアコンポーネントを配布する条件として、当該コンポーネントのソースコードの入手を可能にするよう求めているものがあります。当該「EULA」の対象となるソフトウェアコンポーネントについての問い合わせは、マクスゼンテクニカルセンターへお願いいたします。

また、本製品のソフトウェアコンポーネントには、開発もしくは作成したソフトウェアも含まれており、これらソフトウェア及びそれに付帯したドキュメント類には、所有権が存在し、著作権法、国際条約条項及び他の準拠法によって保護されています。「EULA」の適用を受けない開発もしくは作成したソフトウェアコンポーネントは、ソースコード提供の対象とはなりませんのでご了承ください。

ご購入いただいた本製品は、製品として、弊社所定の保証をいたします。ただし、「EULA」に基づいて配布されるソフトウェアコンポーネントには、著作権者または第三者の保証がないことを前提に、お客様がご自身でご利用になられることが認められるものがあります。この場合、当該ソフトウェアコンポーネントは無償でお客様に使用許諾されますので、適用法令の範囲内で、当該ソフトウェアコンポーネントの保証は一切ありません。著作権やその他の第三者の権利等については、一切の保証がなく、“as is”(現状)の状態で、かつ、明示か黙示であるかを問わず一切の保証をつけないで、当該ソフトウェアコンポーネントが提供されます。ここでいう保証とは、市場性や特定目的適合性についての黙示の保証も含まれますが、それに限定されるものではありません。当該ソフトウェアコンポーネントの品質や性能に関するすべてのリスクはお客様が負うものとします。また、当該ソフトウェアコンポーネントに欠陥があるとわかった場合、それに伴う一切の派生費用や修理・訂正に要する費用は、一切の責任を負いません。適用法令の定め、又は書面による合意がある場合を除き、著作権者や上記許諾を受けて当該ソフトウェアコンポーネントの変更・再配布を為し得る者は、当該ソフトウェアコンポーネントを使用したこと、又は使用できないことに起因する一切の損害についてなんらの責任も負いません。著作権者や第三者が、そのような損害の発生する可能性について知らされていた場合でも同様です。なお、ここでいう損害には、通常損害、特別損害、偶発損害、間接損害が含まれます(データの消失、又はその正確さの喪失、お客様や第三者が被った損失、他のソフトウェアとのインタフェースの不適合化等も含まれますが、これに限定されるものではありません)。当該ソフトウェアコンポーネントの使用条件や遵守いただかなければならない事項等の詳細は、各「EULA」をお読みください。

本製品に組み込まれた「EULA」の対象となるソフトウェアコンポーネントは、以下のとおりです。これらソフトウェアコンポーネントをお客様自身でご利用いただく場合は、対応する「EULA」をよく読んでから、ご利用くださるようお願いいたします。なお、各「EULA」は第三者による規定であるため、原文(英文)を記載します。

本製品で使われるフリーソフトウェアコンポーネントに関するエンドユーザーライセンスアグリーメント原文(英文)

対応ソフトウェアモジュール	
Linux Kernel Busybox	Exhibit A
Glibc Gcc	Exhibit B
Malloc	Exhibit C
Yamon	Yamon
	Access

ソフトウェアコンポーネントに関する エンドユーザーライセンスアグリーメント原文(英文)

Exhibit A

GNU GENERAL PUBLIC LICENSE Version 2, June 1991
Copyright © 1989, 1991 Free Software Foundation, Inc.
59 Temple Place, Suite 330, Boston, MA 02111-1307 USA
Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software - to make sure the software is free for all its users. This General Public License applies to most of the Free Software Foundation's software and to any other program whose authors commit to using it. (Some other Free Software Foundation software is covered by the GNU Library General Public License instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software or use pieces of it in new free programs; and that you know you can do these things.

To protect your rights, we need to make restrictions that forbid anyone to deny you these rights or to ask you to surrender the rights. These restrictions translate to certain responsibilities for you if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether gratis or for a fee, you must give the recipients all the rights that you have. You must make sure that they, too, receive or can get the source code. And you must show them these terms so they know their rights.

We protect your rights with two steps: (1) copyright the software, and (2) offer you this license which gives you legal permission to copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make certain that everyone understands that there is no warranty for this free software. If the software is modified by someone else and passed on, we want its recipients to know that what they have is not the original, so that any problems introduced by others will not reflect on the original author's reputations.

Finally, any free program is threatened constantly by software patents. We wish to avoid the danger that redistributors of a free program will accidently infringe someone's patent, in effect making the program proprietary. To prevent this, we have made it clear that any patent must be licensed for everyone's free use or not licensed at all.

The precise terms and conditions for copying, distribution and modification follow.

GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. (Hereafter, this license is referred to as the "program" or work, and a "work based on the Program" means either the Program or any derivative work under copyright law; that is to say, a work containing the Program or a portion of it, either verbatim or not, with or without modifications, or translated into another language. (Hereinafter, translation is included without limitation in the term "modification.") Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.
2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or that you expressly provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

This is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or

- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or

4. Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only if the original distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program for any work based on the Program, you indicate your acceptance of this license to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all.

For example, if a patent license would permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program. If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the purpose of protecting the integrity of the free software system as a whole, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW, EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL THE AUTHOR OR DISTRIBUTORS BE LIABLE TO ANY PARTY FOR DAMAGES, INCLUDING BUT NOT LIMITED TO, LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING BUT NOT LIMITED TO, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED

その他

ソフトウェアコンポーネントに関する エンドユーザーライセンスアグリーメント原文(英文 (つづき))

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他

BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty, and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<One line to give the program's name and a brief idea of what it does.>

Copyright © 19yy -name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail. If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright © 19yy name of author Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type `show w'. This is free software, and you are welcome to redistribute it under certain conditions; type `show c' for details.

The hypothetical commands `show w' and `show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than `show w' and `show c'; they could even be mouse-clicked or menu items - whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoodyne, Inc., hereby disclaims all copyright interest in the program `Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989 Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

Exhibit B

GNU LESSER GENERAL PUBLIC LICENSE Version 2.1, February 1999

Copyright © 1991, 1999 Free Software Foundation, Inc. 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

[This is the first released version of the Lesser GPL. It also counts as the successor of the GNU Library Public License, version 2, hence the version number 2.1.]

Preamble

The licenses for most software are designed to take away your freedom to share and change it. By contrast, the GNU General Public License is intended to guarantee your freedom to share and change free software - to make sure the software is free for all its users.

This license, the Lesser General Public License, applies to some specially designated software packages - typically libraries - of the Free Software Foundation and other authors who decide to use it. You can use it too, but we suggest you first think carefully about whether this license or the ordinary General Public License is the better strategy to use in any particular case, based on the explanations below.

When we speak of free software, we are referring to freedom of use, not price. Our General Public Licenses are designed to make sure that you have the freedom to distribute copies of free software (and charge for this service if you wish), that you receive source code or can get it if you want it, that you can change the software and use pieces of it in new free programs; and that you are informed that you can do these things.

To protect your rights, we need to make restrictions that forbid distributors to deny you these rights or to ask you to surrender these rights. These restrictions translate to certain responsibilities for you if you distribute copies of the library or if you modify it.

For example, if you distribute copies of the library, whether gratis or for a fee, you must give the recipients all the rights that we gave you. You must make sure that they, too, receive or can get the source code. If you link other code with the library, you must provide complete object files to the recipients, so that they can link them with the library after making changes to the library and recompiling it. And you must show them these terms so they know their rights.

We protect your rights with a two-step method: (1) we copyright the library, and (2) we offer you this license, which gives you legal permission to copy, distribute and/or modify the library.

To protect each distributor, we want to make it very clear that there is no warranty for the free library. Also, if the library is modified by someone else and passed on, the recipients should know that what they have is not the original version, so that the original author's reputation will not be affected by problems that might be introduced by others.

Finally, software patents pose a constant threat to the existence of any free program. We wish to make sure that a company cannot effectively restrict the users of a free program by obtaining a restrictive license from a patent holder. Therefore, we insist that any patent license obtained for a version of the library must be consistent with the full freedom of use specified in this license.

Most GNU software, including some libraries, is covered by the ordinary GNU General Public License. This license, the GNU Lesser General Public License, applies to certain designated libraries, and is quite different from the ordinary General Public License. We use this license for certain libraries in order to permit linking those libraries into non-free programs.

When a program is linked with a library, whether statically or using a shared library, the combination of the two is legally speaking a combined work, a derivative of the original library. The ordinary General Public License therefore permits such linking only if the entire combination fits its criteria of freedom. The Lesser General Public License permits more lax criteria for linking other code with the library.

We call this license the "Lesser" General Public License because it does Less to protect the user's freedom than the ordinary General Public License. It also provides other free software developers Less of an advantage over competing non-free programs. These disadvantages are the reason we use the ordinary General Public License for many libraries. However, the Lesser License provides advantages in certain special circumstances.

For example, on rare occasions, there may be a special need to encourage the widest possible use of a certain library, so that it becomes a de-facto standard. To achieve this, non-free programs must be allowed to use the library. A more frequent case is that a free library does the same job as widely used non-free libraries.

In this case, there is little to gain by limiting the free library to free software only, so we use the Lesser General Public License.

In other cases, permission to use a particular library in non-free programs enables a greater number of people to use a large body of free software. For example, permission to use the GNU C Library in non-free programs enables many more people to use the whole GNU operating system, as well as its variant, the GNU/Linux operating system.

Although the Lesser General Public License is Less protective of the users' freedom, it does ensure that the user of a program that is linked with the Library has the freedom and the wherewithal to run that program using a modified version of the Library.

The precise terms and conditions for copying, distribution and modification follow. Pay close attention to the differences between the words "library" and "work" that uses the library". The former contains code derived from the library, whereas the latter must be combined with the library in order to run.

GNU LESSER GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License Agreement applies to any software library or other program which contains a notice placed by the copyright holder or other authorized party saying it may be distributed under the terms of this Lesser General Public License (also called "this License"). Each licensee is addressed as "you".

A "library" means a collection of software functions and/or data prepared so as to be conveniently linked with application programs (which use some of those functions and data) to form executable programs.

The "Library", below, refers to any such software library or work which has been distributed under these terms. A "work based on the Library" means either the Library or any derivative work under copyright law that is to say, a work containing the Library or a portion of it, either verbatim or with modifications and/or translated straightforwardly into another language. (Hereinafter, translation is included without limitation in the term "modification".)

"Source code" for a work means the preferred form of the work for making modifications to it. For a library, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the library.

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running a program using the Library is not restricted, and output from such a program is covered only if its contents constitute a work based on the Library (independent of the use of the Library in a tool for writing it). Whether that is true depends on what the Library does and what the program that uses the Library does.

1. You may copy and distribute verbatim copies of the Library's complete source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and distribute a copy of this License along with the Library. You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Library or any portion of it, thus forming a work based on the Library, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) The modified work must itself be a software library.
- b) You must cause the files modified to carry prominent notices stating that you changed the files and the date of any change.
- c) You must cause the whole of the work to be licensed at no charge to all third parties under the terms of this License.
- d) If a facility in the modified Library refers to a function or a table of data to be supplied by an application program that uses the facility, other than as an argument passed when the facility is invoked, then you must make a good faith effort to ensure that, in the event an application does not supply such function or table, the facility still operates, and performs whatever part of its purpose remains meaningful. (For example, a function in a library to compute square roots has a purpose that is entirely well-defined independent of the application. Therefore, Subsection 2d requires that any application-supplied function or table used by this function must still compute square roots.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Library, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Library, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

This is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Library.

In addition, mere aggregation of another work not based on the Library with the Library (or with a work based on the Library) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may opt to apply the terms of the ordinary GNU General Public License instead of this License to a given copy of the Library. To do this, you must alter all the notices that refer to this License, so that they refer to the ordinary GNU General Public License, version 2, instead of to this License. If a newer version than version 2 of the ordinary GNU General Public License has appeared, then you can specify that version instead if you wish. Do not make any other change in these notices.

ソフトウェアコンポーネントに関する エンドユーザライセンスアグリーメント原文(英文)(つづき)

Once this change is made in a given copy, it is irrevocable for that copy, so the ordinary GNU General Public License applies to all subsequent copies and derivative works made from that copy.

This option is useful when you wish to copy part of the code of the Library into a program that is not a Library.

4. You may copy and distribute the Library (or a portion or derivative of it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange. If distribution of object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place satisfies the requirement to distribute the source code, even though third parties are not compelled to copy the source along with the object code.
5. A program that contains no derivative of any portion of the Library, but is designed to work with the Library by being compiled or linked with it, is called a "work that uses the Library". Such a work, in isolation, is not a derivative work of the Library, and therefore falls outside the scope of this License.

However, linking a "work that uses the Library" with the Library creates an executable that is a derivative of the Library (because it contains portions of the Library), rather than a "work that uses the library". The executable is therefore covered by this License. Section 6 states terms for distribution of such executables.

When a "work that uses the Library" uses material from a header file that is part of the Library, the object code for the work may be a derivative work of the Library even though the source code is not. Whether this is true is especially significant if the work can be linked without the Library, or if the work is itself a library. The threshold for this to happen is not precisely defined by law.

If such an object file uses only numerical parameters, data structure layouts and accessors, and small macros and small inline functions (ten lines or less in length), then the use of the object file is unrestricted, regardless of whether it is legally a derivative work. (Executables containing this object code plus portions of the Library will still fall under this License.)

Otherwise, if the work is a derivative of the Library, you may distribute the object code for the work under the terms of Section 6. Any executables containing that work also fall under Section 6, whether or not they are linked directly with the Library itself.

6. As an exception to the Sections above, you may also combine or link a "work that uses the Library" with the Library to produce a work containing portions of the Library, and distribute that work under terms of your choice, provided that the terms permit modification of the work for the customer's own use and reverse engineering for debugging and repair activities.
- You must give prominent notice with each copy of the work that the Library is used in it and that the Library and its use are covered by this License. You must supply a copy of this License. If the work during execution displays copyright notices, you must include the copyright notice for the Library among them, as well as a reference directing the user to the copy of this License. Also, you must do one of these things:

- Accompany the work with the complete corresponding machine-readable source code for the Library including whatever changes were used in the work (which must be distributed under Sections 1 and 2 above); and, if the work is an executable linked with the Library, with the complete machine-readable "work that uses the Library", as object code and/or source code, so that the user can modify the Library and then relink to produce a modified executable containing the modified Library. (It is understood that the user who changes the contents of definitions files in the Library will not necessarily be able to recompile the application to use the modified definitions.)
- Use a suitable shared library mechanism for linking with the Library. A suitable mechanism is one that (1) uses at run time a copy of the library already present on the user's computer system, rather than copying library functions into the executable, and (2) will operate properly with a modified version of the library, if the user installs one, as long as the modified version is interface-compatible with the version that the work was made with.
- Accompany the work with a written offer, valid for at least three years, to give the same user the materials specified in Subsection 6a, above, for a charge no more than the cost of performing this distribution.
- If distribution of the work is made by offering access to copy from a designated place, offer equivalent access to copy the above specified materials from the same place.
- Verify that the user has already received a copy of these materials or that you have already sent this user a copy.

For an executable, the required form of the "work that uses the Library" must include any data and utility programs needed for reproducing the executable from it. However, as a special exception, the materials to be distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiled, linked and/or loaded) by the operating system on which the executable runs, unless that component itself accompanies the executable.

It may happen that this requirement contradicts the license restrictions of other proprietary libraries that do not normally accompany the operating system. Such a contradiction means you cannot use both them and the Library together in an executable that you distribute.

7. You may place library facilities that are a work based on the Library side-by-side in a single library together with other library facilities not covered by this License, and distribute such a combined library, provided that the separate distribution of the work based on the Library and of the other library facilities is otherwise permitted, and provided that you do these two things:
- Accompany the combined library with a copy of the same work based on the Library, uncombined with any other library facilities. This must be distributed under the terms of the Sections above.
 - Give prominent notice with the combined library of the fact that part of it is a work based on the Library, and explaining where to find the accompanying uncombined form of the same work.
8. You may not copy, modify, subsume, link with, or distribute the Library except as expressly provided under this License. Any attempt otherwise to copy, modify, subsume, link with, or distribute the Library is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.
9. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Library or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Library (or any work based on the Library), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Library or works based on it.

10. Each time you redistribute the Library (or any work based on the Library), the recipient automatically receives a license from the original licensor to copy, distribute, link with or modify the Library subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein, you are not responsible for enforcing compliance by third parties with this License.

11. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that conflict with the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Library at all.

For example, if a patent license would not permit royalty-free redistribution of the Library by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Library.

12. If the section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply, and the section as a whole is intended to apply in other circumstances.

It is the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system, and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

12. If the distribution and/or use of the Library is restricted in certain countries either by patents or by copyright interfaces, the original copyright holder who places the Library under this License may add to the license any additional distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

13. The Free Software Foundation may publish revised and/or new versions of the Lesser General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Library specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Library does not specify a license version number, you may choose any version ever published by the Free Software Foundation.

14. If you wish to incorporate parts of the Library into other free programs whose distribution conditions are incompatible with these, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

NO WARRANTY

15. BECAUSE THE LIBRARY IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE LIBRARY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE LIBRARY "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE LIBRARY IS WITH YOU. SHOULD THE LIBRARY PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

16. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE LIBRARY AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE LIBRARY (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE LIBRARY TO OPERATE WITH ANY OTHER SOFTWARE), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

How to Apply These Terms to Your Libraries

If you develop a new library, and you want it to be of the greatest possible use to the public, we recommend making it free software that everyone can redistribute and change. You can do so by permitting redistribution under these terms (or, alternatively, under the terms of the ordinary GNU Public License).

To apply these terms to your library, do the following notices to the library. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty, and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the library's name and a brief idea of what it does.>

Copyright © <year> <name of author>

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc, 59 Temple Place, Suite 330, Boston, MA 02111-1307 USA

Also add information on how to contact you by electronic and paper mail.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "no disclaimer" for the library. If necessary, here is a sample after the names: Yooyocine, Inc, hereby disclaims all copyright interest in the library 'foo' (a library for tweaking knobs) written by James Random Hacker.

<signature of T. Coon>, 1 April 1990

T. Coon, President of Vice

That's all there is to it!

ソフトウェアコンポーネントに関する エンドユーザーライセンスアグリーメント原文(英文) (つづき)

Exhibit C

This is a version (aka malloc) of malloc / free / realloc written by Doug Lea and released to the public domain. Use, modify, and redistribute this code without permission or acknowledgement in any way you wish. Send questions, comments, complaints, performance data, etc to dl@cs.cmu.edu

VERSION 2.7.2 Sat Aug 17 09:07:30 2002 Doug Lea (dl at cee)

Note: There may be an updated version of this malloc obtainable at <http://gee.cs.oswego.edu/pub/misc/malloc.c>
Check before installing!

YAMON;

SOFTWARE LICENSE AGREEMENT ("Agreement")

IMPORTANT- This Agreement legally binds you (either an individual or an entity), the end user ("Licensee"), and MIPS Technologies, Inc. ("MIPS") whose street address and fax information is 1225 Charleston Road, Mountain View, California 94043, Fax Number (650) 567-5154.

1. DEFINITIONS-

The following definitions apply to this Agreement. "Authorized Product" shall mean a product developed by MIPS or under a license that was granted by MIPS.

"Documentation" shall mean documents (including any updates provided or made available by MIPS solely at its discretion), and any information, whether in written, magnetic media, electronic or other format, provided to Licensee describing the Software, its operation and matters relating to its use.

"GPL Materials" shall mean any source or object code provided by MIPS to Licensee under the terms of the GNU General Public License, Version 2, June 1991 or later ("GNU GPL").

"IP Rights" shall mean intellectual property rights including but not limited to, patent, copyright, trade secret and mask work rights.

"Licensee Code Modifications" shall mean any modifications to YAMON Code and/or other code provided to Licensee by MIPS, made by or on behalf of Licensee.

"MIPS Code Modifications" shall mean modifications to YAMON Code and/or other code provided to Licensee by MIPS or any third party granted by MIPS, wherein such third party grants back to MIPS a license under such code modifications with the rights to sublicense and grant further sublicenses.

"MIPS Deliverables" shall mean the Software, Documentation and any other information or materials provided by MIPS to Licensee pursuant to this Agreement except for GPL Materials.

"Software" shall mean software containing YAMON Code, any other source and/or object code provided by MIPS at its sole discretion, and any Documentation contained in such software at MIPS's sole discretion.

"YAMON Code" shall mean source and/or object code for the YAMON monitor software, Ver. 1.01, or later (including any updates provided or made available by MIPS solely at its discretion).

2. MIPS LICENSE GRANTS

- (a) Subject to Licensee's compliance with the terms and conditions of this Agreement and payment of any fees owed to MIPS, MIPS grants to Licensee a non-exclusive, worldwide, non-transferable, royalty-free, fully-paid limited right and license to:
- (i) use the MIPS Deliverables at Licensee's facilities solely for Licensee's internal evaluation and development purposes (and to use, copy and reproduce and have reproduced Documentation solely to facilitate those uses of MIPS Deliverables that are allowed hereunder), and to sublicense Licensee's rights granted in this Subsection 2(a)(i) to Licensee's consultants for their use of the MIPS Deliverables at their facilities for their internal evaluation and development purposes;
- (ii) make, use, import, copy, reproduce, have reproduced, modify, create derivative works from YAMON Code only in conjunction with making, using, importing, offering for sale and selling or otherwise distributing Authorized Product and only for use exclusively with such Authorized Product, and to sublicense its rights granted in this Subsection 2(a)(ii), including the right to grant further sublicenses, provided that with respect to any sublicense, (A) any IP Rights arising in any modification or derivative work created by such sublicense shall be licensed back to MIPS together with the right by MIPS to sublicense such rights and grant further sublicenses, and (B) the obligations of Subsection 2(c) below shall apply equally to any YAMON Code modified and/or sublicense by such sublicense. These obligations shall be deemed to have been satisfied by Licensee's delivery of a copy of this Agreement to its sublicensee(s).
- (b) MIPS further grants to Licensee a non-exclusive, worldwide, non-transferable, royalty-free, fully-paid limited right and license under MIPS IP Rights in any MIPS Code Modifications in existence now, or at any time during the term of this Agreement (including those IP Rights assigned to MIPS or licensed to MIPS with sufficient sublicensing rights to satisfy the license grant in this Subsection 2(b)) to the limited extent that Licensee may make, use and import such MIPS

Code Modifications only in conjunction with making, using, importing, offering for sale and selling or otherwise distributing Authorized Product and only for use exclusively with such Authorized Product, and sublicense its rights granted in this Subsection 2(b), including the right to grant further sublicenses under the preconditions set forth in Subsection 2(a)(ii) above. Licensee acknowledges and agrees that MIPS (or any third party) is under no obligation to deliver MIPS Code Modifications; rather, this license right is intended solely to provide a freedom to use such modifications when created independently by Licensee or any sublicensee thereof.

- (c) Any YAMON Code modified and/or sublicensed pursuant to this Agreement must (i) contain all copyright and other notices contained in the original YAMON Code provided by MIPS to Licensee, (ii) cause modified files to carry prominent notices stating that Licensee (or any sublicensee) changed the files and the date of any change, and (iii) be sublicensed under terms that disclaim all warranties from MIPS and limit all liability of MIPS pursuant to Sections 8, 9, 11 and 2 here in.
- (d) All other rights to the MIPS Deliverables not stated in the Section 2 are reserved to MIPS. Except as set out in this Section 2, Licensee shall not rent, lease, sell, sublicense, assign, loan, or otherwise transfer or convey the MIPS Deliverables to any third party. These license grants are effective as of the Effective Date. No license is granted for any other purpose.
- (e) To the extent MIPS provides any GPL Materials to Licensee, use of such materials shall, notwithstanding any provision of this Agreement to the contrary, be governed by the GNU GPL.

3. LICENSEE CODE MODIFICATIONS

In partial consideration for the rights and licenses granted under Section 2 herein, Licensee agrees to grant and does hereby grant to MIPS a perpetual, irrevocable, non-exclusive worldwide, royalty-free, fully-paid limited right and license under Licensee's IP Rights in any Licensee Code Modifications (including those IP Rights assigned to Licensee or licensed to Licensee with sufficient sublicensing right to satisfy the license grant in this Section 3) to the extent that MIPS may make, use and import such Licensee Code Modifications only in conjunction with making, using, importing, offering for sale and selling or otherwise distributing Authorized Product and only for use exclusively with such Authorized Product, and sublicense its rights granted in this Section 3, including the right to grant further sublicenses. MIPS acknowledges and agrees that Licensee (or any third party) is under no obligation to deliver Licensee Code Modifications; rather, this license right is intended solely to provide a freedom to use such modifications when created independently by MIPS or any sublicensee thereof.

4. OWNERSHIP AND PREVENTION OF MISUSE OF MIPS DELIVERABLES

- (a) This Agreement does not confer any rights of ownership in or to the MIPS Deliverables to Licensee; Licensee does not acquire any rights, express or implied, in the MIPS Deliverables other than those specified in Section 2 above. Licensee agrees that all title and IP Rights in the MIPS Deliverables remain in MIPS (subject only, if and to the extent applicable, to the rights of a MIPS supplier with respect to a particular MIPS Deliverable(s)). Licensee agrees that it shall take all reasonable steps to prevent unauthorized copying of the MIPS Deliverables.
- (b) MIPS owns all right, title and interest in the YAMON Code and other MIPS Deliverables (subject only, if and to the extent applicable, to the rights of a MIPS supplier with respect to a particular MIPS Deliverable(s)). Licensee shall own all right, title and interest in the modifications and derivative works of the YAMON Code created by Licensee, subject to MIPS' rights in the underlying original YAMON Code as provided under this Agreement.
- (c) Licensee agrees to provide reasonable feedback to MIPS including, but not limited to, usability of the MIPS Deliverables. All feedback made by Licensee shall be the property of MIPS and may be used by MIPS for any purpose.
- (d) Licensee shall make all reasonable efforts to discontinue distribution, copying and use of any MIPS Deliverables that are replaced by a new, upgraded or updated version of any such MIPS Deliverables, including distribution to any sublicensee of such new, upgraded or updated versions.
- (e) Licensee shall not make any statement of any kind or in any format, that any MIPS Deliverable is certified, or that its performance in connection with any product is warranted, indemnified or guaranteed in any way by MIPS or any party on MIPS' behalf. (f) Neither YAMON, MIPS nor any other trademark owned or licensed in by MIPS may be used by Licensee, any sublicensee thereof or any party on their behalf without prior written consent by MIPS, including at MIPS' sole discretion a trademark license agreement preapproved by MIPS.

5. ASSIGNMENT

Licensee may not assign or otherwise transfer any of its rights or obligations under this Agreement to any third party without MIPS' prior written consent, and any attempt to do so will be null and void. This prohibition against Licensee's assignment shall apply even in the event of merger, re-organization, or when a third party purchases all substantially

ソフトウェアコンポーネントに関する エンドユーザーライセンスアグリーメント原文(英文) (つづき)

all of Licensee's assets. Subject to the foregoing, this Agreement will be binding upon and will inure to the benefit of the parties and their respective permitted successors and assigns.

6. LIMITATIONS OF MIPS SUPPORT-RELATED OBLIGATIONS

This Agreement does not entitle Licensee to hard-copy documentation or to support, training or maintenance of any kind from MIPS, including documentary, technical, or telephone assistance.

7. TERM AND TERMINATION

(a) This Agreement shall commence on the Effective Date. If Licensee fails to perform or violates any obligation under this Agreement, then upon thirty (30) days written notice to Licensee specifying such default (the "Default Notice"), MIPS may terminate this Agreement without liability, unless the breach specified in the Default Notice has been cured within the thirty (30) day period. This 30-day period may be extended upon mutual, written consent between the parties.

(b) Upon the termination of this Agreement due to Licensee's material breach hereof, Licensee shall (1) immediately discontinue use of the MIPS Deliverables; (2) promptly return all MIPS Deliverables to MIPS; (3) destroy all copies of MIPS Deliverables made by Licensee while in breach of this Agreement. All licensees granted hereunder shall terminate as of the effective date of termination.

(c) The rights and obligations under this Agreement which by their nature should survive termination, including but not limited to Sections 9 - 16, will remain in effect after expiration or termination hereof. Subject to Licensee's compliance with the surviving sections of this Agreement identified herein, any sublicensees rightfully granted and derivative works rightfully developed pursuant to Section 2 shall survive the termination of this Agreement.

8. DISCLAIMER OF WARRANTIES

THE MIPS DELIVERABLES ARE PROVIDED "AS IS". MIPS MAKES NO WARRANTIES WITH REGARD TO ANY OF THE MIPS DELIVERABLES, AND EXPRESSLY DISCLAIMS ALL WARRANTIES, WHETHER EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF TITLE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OF THIRD PARTY RIGHTS.

9. LIMITATION OF LIABILITY AND REMEDY

(a) Licensee acknowledges the MIPS Deliverables are provided to Licensee only for the purpose set forth in Section 2. Licensee shall hold harmless and indemnify MIPS from any and all actual or threatened liabilities, claims or defenses based on the sublicensing, use, copying, installation, demonstration and/or modification of any of the MIPS Deliverables by Licensee, any sublicensee of Licensee or any party on their behalf. Licensee shall have sole responsibility for adequate protection and backup of any data and/or equipment used with the MIPS Deliverables, and Licensee shall hold harmless and indemnify MIPS from any and all actual or threatened liabilities, claims and defenses for lost data, re-run time, inaccurate output, work delays or lost profits resulting from use and/or modification of the MIPS Deliverables, or any portion thereof, under this Agreement. Licensee expressly acknowledges and agrees that any research or development performed with respect to the MIPS Deliverables is done entirely at Licensee's own risk.

(b) NEITHER PARTY SHALL BE LIABLE TO THE OTHER PARTY OR TO ANY THIRD PARTY FOR ANY DAMAGES INCLUDING, BUT NOT LIMITED TO, SPECIAL, CONSEQUENTIAL, PUNITIVE, INDIRECT, EXEMPLARY OR INCIDENTAL DAMAGES, WHETHER SUCH DAMAGES ARISE UNDER A TORT, CONTRACT OR OTHER CLAIM, OR DAMAGES TO SYSTEMS, DATA OR SOFTWARE, EVEN IF SUCH PARTY HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES. THIS LIMITATION ON LIABILITY SHALL SURVIVE EVEN IF THE LIMITED REMEDY PROVIDED HEREIN FAILS OF ITS ESSENTIAL PURPOSE. IN NO CASE WILL MIPS' LIABILITY FOR DAMAGES UNDER THIS AGREEMENT EXCEED THE AMOUNTS RECEIVED BY MIPS AS FEES UNDER THIS AGREEMENT.

(c) NEITHER PARTY SHALL BE LIABLE TO THE OTHER PARTY OR TO ANY THIRD PARTY FOR ANY DAMAGES INCLUDING, BUT NOT LIMITED TO, SPECIAL, CONSEQUENTIAL, PUNITIVE, INDIRECT, EXEMPLARY OR INCIDENTAL DAMAGES, WHETHER SUCH DAMAGES ARISE UNDER A TORT, CONTRACT OR OTHER CLAIM, OR DAMAGES TO SYSTEMS, DATA OR SOFTWARE, EVEN IF SUCH PARTY HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES. THIS LIMITATION ON LIABILITY SHALL SURVIVE EVEN IF THE LIMITED REMEDY PROVIDED HEREIN FAILS OF ITS ESSENTIAL PURPOSE. IN NO CASE WILL MIPS' LIABILITY FOR DAMAGES UNDER THIS AGREEMENT EXCEED THE AMOUNTS RECEIVED BY MIPS AS FEES UNDER THIS AGREEMENT.

10. WAIVER; MODIFICATION

Any waiver of any right or default hereunder will be effective only in the instance given and will not operate as or imply a waiver of any other or similar right or default on any subsequent occasion. No waiver or modification of this Agreement or of any provision hereof will be effective unless in writing and signed by the party against whom such waiver or modification is sought to be enforced.

12. SEVERABILITY

In the event any provision of this Agreement (or portion thereof) is determined to be invalid, illegal or otherwise unenforceable, then such provision will, to the extent permitted, not be voided but will instead be construed to give effect to its intent to the maximum extent permissible under applicable law and the remainder of this Agreement will remain in full force and effect according to its terms. IN THE EVENT THAT ANY REMEDY HEREUNDER IS DETERMINED TO HAVE FAILED OF ITS ESSENTIAL PURPOSE, ALL LIMITATIONS OF LIABILITY AND EXCLUSIONS OF DAMAGES SHALL REMAIN IN EFFECT.

13. RIGHTS IN DATA

Licensee acknowledges that all software and software related items licensed by MIPS to Licensee pursuant to this Agreement are "Commercial Computer Software" or "Commercial Computer Software Documentation" as defined in FAR 1.2212 for civilian agencies and DFARS 227.7202 for military agencies, and that in the event that Licensee is permitted under this Agreement to provide such items to the U.S. government, such items shall be provided under terms at least as restrictive as the terms of this Agreement.

14. MISCELLANEOUS

(a) The MIPS Deliverables and GPL Materials may be subject to U.S. export or import control laws and export or import regulations of other countries. Licensee agrees to comply strictly with all such laws and regulations and acknowledges that it has the responsibility to obtain such licenses to export, re-export, or import as may be required after delivery to Licensee. Licensee shall indemnify, defend and hold MIPS harmless from any damages, fees, costs, fines, expenses, charges and any actual or threatened civil and/or criminal claims or defenses arising from any failure of Licensee and/or its customers to comply with any obligations arising under this Section 14(a).

(b) Any notice required or permitted by this Agreement must be in writing and must be sent by email, by facsimile, by recognized commercial overnight courier, or mailed by United States registered mail, effective only upon receipt, to the legal departments of MIPS or Licensee (if Licensee has no legal department, then to an officer of Licensee, a contact person specified by Licensee or Licensee's place of business).

(c) The headings contained herein are for the convenience of reference only and are not intended to define, limit, expand or describe the scope or intent of any clause or provision of this Agreement.

(d) The parties hereto are independent contractors, and nothing herein shall be construed to create an agency, joint venture, partnership or other form of business association between the parties hereto.

(e) Licensee acknowledges that, in providing Licensee with the MIPS Deliverables, MIPS has relied upon Licensee's agreement to be bound by the terms of this Agreement. Licensee further acknowledges that it has read, understood, and agreed to be bound by the terms of this Agreement, and hereby reaffirms its acceptance of those terms.

15. GOVERNING LAW AND JURISDICTION

This Agreement shall be governed by the laws of the State of California, excluding California's choice of law rules. With the exception of MIPS' rights to enforce its intellectual property rights in the MIPS Deliverables, all disputes arising out of this Agreement shall be subject to the exclusive jurisdiction and venue of the state and federal courts located in Santa Clara County, California, and the parties consent to the personal and exclusive jurisdiction and venue of these courts. The parties expressly disclaim the application of the United Nations Convention on the International Sale of Goods to this Agreement.

16. ENTIRE AGREEMENT

This Agreement and the GNU GPL constitute the entire agreement between MIPS and Licensee regarding the MIPS Deliverables and GPL Materials provided to Licensee hereunder, and shall supersede and control over any other prior or contemporaneous shrinkwrap and/or clickwrap agreements regarding the same. Any additions or modifications must be made in a subsequent, written agreement signed by both parties.

ソフトウェアコンポーネントに関する エンドユーザーライセンスアグリーメント原文(英文) (つづき)

オープンソースソフトウェア

【オープンソースソフトウェアの使用条件が記載されたURL】

(a)ijgjpeg	http://www.ijg.org/
(b)zlib	http://www.zlib.net/zlib_license.html
(c)libpng	http://www.libpng.org/pub/png/src/libpng-LICENSE.txt

【本契約締結時点でのオープンソースソフトウェアの使用条件】
-<Image Decoder Modules>

- (a) ijgjpeg
(b) zlib
(c) libpng

(a) ijgjpeg

ijgjpeg License Terms

The authors make NO WARRANTY or representation, either express or implied, with respect to this software, its quality, accuracy, merchantability, or fitness for a particular purpose. This software is provided "AS IS", and you, its user, assume the entire risk as to its quality and accuracy.

This software is copyright (C) 1991-1998, Thomas G. Lane. All Rights Reserved except as specified below.

Permission is hereby granted to use, copy, modify, and distribute this software (or portions thereof) for any purpose, without fee, subject to these conditions:

- (1) If any part of the source code for this software is distributed, then this README file must be included, with this copyright and nowarranty notice unaltered, and any additions, deletions, or changes to the original files must be clearly indicated in accompanying documentation.
- (2) If only executable code is distributed, then the accompanying documentation must state that "this software is based in part on the work of the Independent JPEG Group".
- (3) Permission for use of this software is granted only if the user accepts full responsibility for any undesirable consequences; the authors accept NO LIABILITY for damages of any kind.

These conditions apply to any software derived from or based on the IJG code, not just to the unmodified library. If you use our work, you ought to acknowledge us.

Permission is NOT granted for the use of any IJG author's name or company name in advertising or publicity relating to this software or products derived from it. This software may be referred to only as "the Independent JPEG Group's software".

We specifically permit and encourage the use of this software as the basis of commercial products, provided that all warranty or liability claims are assumed by the product vendor.

ansi2knr.c is included in this distribution by permission of L. Peter Deutsch, sole proprietor of its copyright holder, Aladdin Enterprises of Menlo Park, CA. ansi2knr.c is NOT covered by the above copyright and conditions, but instead by the usual distribution terms of the Free Software Foundation; principally, that you must include source code if you redistribute it. (See the file ansi2knr.c for full details.) However, since ansi2knr.c is not needed as part of any program generated from the IJG code, this does not limit you more than the foregoing paragraphs do.

The Unix configuration script "configure" was produced with GNU Autoconf. It is copyright by the Free Software Foundation but is freely distributable. The same holds for its supporting scripts (config.guess, config.sub, Iconfing, Irmains.h). Another support script, installsh, is copyright by MIT, but is also freely distributable.

It appears that the arithmetic coding option of the JPEG spec is covered by patents owned by IBM, AT&T, and Mitsubishi. Hence arithmetic coding cannot legally be used without obtaining one or more licenses. For this reason, support for arithmetic coding has been removed from the free JPEG software. (Since arithmetic coding provides only a marginal gain over the unpatented Huffman mode, it is unlikely that very many implementations will support it.)

So far as we are aware, there are no patent restrictions on the remaining code.

The IJG distribution formerly included code to read and write GIF files.

To avoid entanglement with the Unisys LZW patent, GIF reading support has been removed altogether, and the GIF writer has been simplified to produce "uncompressed GIFs". This technique does not use the LZW algorithm; the resulting GIF files are larger than usual, but are readable by all standard GIF decoders.

We are required to state that The Graphics Interchange Format(c) is the Copyright property of CompuServe Incorporated. GIF(sm) is a Service Mark property of CompuServe Incorporated.

(b) zlib

zlib License Terms

/* zlib.h - interface of the 'zlib' general purpose compression library version 1.2.3, July 18th, 2005

Copyright (C) 1995-2005 Jean-loup Gailly and Mark Adler

This software is provided 'as-is', without any express or implied warranty. In no event will the authors be held liable for any damages arising from the use of this software.

Permission is granted to anyone to use this software for any purpose, including commercial applications, and to alter it and redistribute it freely, subject to the following restrictions:

1. The origin of this software must not be misrepresented; you must not claim that you wrote the original software. If you use this software in a product, an acknowledgment in the product documentation would be appreciated but is not required.
2. Altered source versions must be plainly marked as such, and must not be misrepresented as being the original software.
3. This notice may not be removed or altered from any source distribution.

Jean-loup Gailly jloup@gzip.org
Mark Adler madler@alum.mit.edu

/*

(c)libpng

COPYRIGHT NOTICE, DISCLAIMER, and LICENSE:

If you modify libpng you may insert additional notices immediately following this sentence.

libpng versions 1.2.6, August 15, 2004, through 1.2.18, May 15, 2007, are Copyright (c) 2004, 2006-2007 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as libpng-1.2.5 with the following individual added to the list of Contributing Authors

Cosmin Truta

libpng versions 1.0.7, July 1, 2000, through 1.2.5 - October 3, 2002, are Copyright (c) 2000-2002 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as libpng-1.0.6 with the following individuals added to the list of Contributing Authors

Simon-Pierre Cadieux
Eric S. Raymond
Gilles Vollant

and with the following additions to the disclaimer:

There is no warranty against interference with your enjoyment of the library or against infringement. There is no warranty that our efforts or the library will fulfill any of your particular purposes or needs. This library is provided with all faults, and the entire risk of satisfactory quality, performance, accuracy, and effort is with the user.

libpng versions 0.97, January 1998, through 1.0.6, March 20, 2000, are Copyright (c) 1998, 1999 Glenn Randers-Pehrson, and are distributed according to the same disclaimer and license as libpng-0.96, with the following individuals added to the list of Contributing Authors:

Tom Lane
Glenn Randers-Pehrson
Willem van Schaik

libpng versions 0.89, June 1996, through 0.96, May 1997, are Copyright (c) 1996, 1997 Andreas Dilger Distributed according to the same disclaimer and license as libpng-0.88, with the following individuals added to the list of Contributing Authors:

その他

ソフトウェアコンポーネントに関する エンドユーザーライセンスアグリーメント原文(英文) (つづき)

John Bowler
Kevin Bracey
Sam Bushnell
Magnus Holmgren
Greg Ruelofs
Tom Tanner

libpng versions 0.5, May 1995, through 0.88, January 1996, are Copyright (c) 1995, 1996 Guy Eric Schalnat, Group 42, Inc.

For the purposes of this copyright and license, "Contributing Authors" is defined as the following set of individuals:

Andreas Dilger
Dave Martindale
Guy Eric Schalnat
Paul Schmidt
Tim Wegner

The PNG Reference Library is supplied "AS IS". The Contributing Authors and Group 42, Inc. disclaim all warranties, expressed or implied, including, without limitation, the warranties of merchantability and of fitness for any purpose. The Contributing Authors and Group 42, Inc. assume no liability for direct, indirect, incidental, special, exemplary, or consequential damages, which may result from the use of the PNG Reference Library, even if advised of the possibility of such damage.

Permission is hereby granted to use, copy, modify, and distribute this source code or portions hereof, for any purpose, without fee, subject to the following restrictions:

1. The origin of this source code must not be misrepresented.
2. Altered versions must be plainly marked as such and must not be misrepresented as being the original source.
3. This Copyright notice may not be removed or altered from any source or altered source distribution.

The Contributing Authors and Group 42, Inc. specifically permit, without fee, and encourage the use of this source code as a component to supporting the PNG file format in commercial products. If you use this source code in a product, acknowledgment is not required but would be appreciated.

A "png_get_copyright" function is available, for convenient use in "about" boxes and the like.

```
printf("%s", png_get_copyright(NULL));
```

Also, the PNG logo (in PNG format, of course) is supplied in the files "pngbar.png" and "pngbar.jpg" (88x31) and "pngnow.png" (98x31).

Libpng is OSI Certified Open Source Software. OSI Certified Open Source is a certification mark of the Open Source Initiative.

Glenn Randers-Pehrson
glennrp at users.sourceforge.net
May 15, 2007

ライセンスおよび商標などについて



本製品は、株式会社ACCESSのNetFrontBrowserを搭載しています。ACCESS、NetFrontは、日本国およびその他の国における株式会社ACCESSの商標または登録商標です。

©2009 ACCESS CO., LTD. All rights reserved.

- 本製品の一部分にIndependent JPEG Groupが開発したモジュールが含まれています。
- この製品に含まれているソフトウェアをリバース・エンジニアリング、逆アセンブル、逆アセンブル、逆コンパイル、分解またはその他の方法で解析、及び変更することは禁止されています。CHECKED: K.

ご利用前に

テレビを見る準備

基本の操作

外部機器との接続

調整と設定

その他



株式会社 MOASTORE

株式会社 MOASTORE マクスゼンテクニカルセンター

〒273-0022 千葉県船橋市海神町3-124 TEL:047-401-2668

○本製品には、保証書が付いています。ご購入の販売店名、ご購入年月日のご記入なきものは、無効となりますので必ずご確認ください。

○本製品ならびに本書は、改善のために予告なく変更する場合があります。

○本書の内容の一部または全部の無断転載を禁じます。

○本製品の使用・故障によって生じた、直接・間接の損害については、弊社はその責任を負わないものとします。

●乱丁本・落丁本の場合はお取り替えいたします。販売店、またはテクニカルセンターにご連絡ください。

Copyright © MOASTORE Co.,Ltd. All Rights Reserved.